




ASSEMBLY INSTRUCTION

NP2X-AU-SILENT | 1/4" Professional Phone Plug



A Slide the boot onto the cable.

B Prepare cable as shown.

C Solder the wire ends.

Attention:

Solder shield to marked position.

D Position the chuck onto the cable and align chuck with plugfingers.

Attention:

If using a cable with O.D. > 5.50 mm [0.216 inch] break away this part of the chuck.

E Slide the housing onto the plugfingers with the chuck.

F Finish the installation by tighten the bushing onto the connector.

NEUTRIK AG LI T: +423 / 237 24 24 F: +423 / 232 53 93
NEUTRIK Zürich AG CH T: +41 44 / 736 5010 F: +41 44 / 736 5011
NEUTRIK USA Inc. USA T: +1 732 / 901 9488 F: +1 732 / 901 9608
NEUTRIK (UK) Ltd. UK T: +44 1983 / 811 441 F: +44 1983 / 811 439

NEUTRIK Vertriebs GmbH DE/NL/AT T: +49 8131 / 280 890 F: +49 8131 / 280 830
NEUTRIK France FR T: +33 1 / 4131 6750 F: +33 1 / 4131 0511
NEUTRIK Tokyo Ltd. JP T: +81 3 / 3663 4733 F: +81 3 / 3663 4796
NEUTRIK Hong Kong Ltd. HK T: +852 / 2687 6055 F: +852 / 2687 6052

Draft. Nr.: BDA 218-0 / 3102M1641 | Update: 06.03.2008 | Data subject to change without prior notice. ©2008NEUTRIK®. ALL RIGHTS RESERVED.

www.neutrik.com

NEUTRIK