QUICK START GUIDE

Visit myievo.co.uk to download your software licence.

ievo

Access Control System

ievo micro™

ievo ultimate™

IEVO_BOARD-R4

Caution | IP | reset

INPUT A — Rx / Power — OUTPUT A — Reject / Accept — GND / CK/D1 / D0

INPUT B — Rx / Power — OUTPUT B — Reject / Accept — GND / CK/D1 / D0

CPU / COMMS / ERROR — USB

CDVI Security to Access

Made in the UK

Power In / 12VDC / 5VDC / 3.3VDC / CPU Power

SERIAL:

MAC:

IP ADDRESS:

Network Out

Network In

Power In

12-24V AC/DC 1.2A [max]

ievo Interface Board

Wiegand Output A

Wiegand Output B

Twisted and shielded cable
min 22 AWG (0.6mm)
max 75m distance (>25m solid core)

Network Out
Provides a network bridge to a single ACU

Network In
Network connection to PC or LAN
Default IP addres: 192.168.1.225

Non-Polarised Power Input
POE/Network input when using
the POE interface board

Network Switch

Power Supply
2A 12/24V

## Cable Recommendations

Supplied cable: Up to 5m
Cat6 SFTP Ethernet braid-shielded cable
with foil-shielded pairs

Up to 50m
Cat5e/Cat6a SFTP Stranded-conductor
with shielded RJ45 connectors

Up to 90m
Cat5e/Cat6a SFTP Solid-conductor
with shielded RJ45 connectors