

► Models CP-PB and CP-BG

# Replacement Parts and Optional Accessories

## REPLACEMENT PARTS

### Break Glass Call Points Replacement Parts

<b>K859902275A</b>	Break Glass Panel, 5-Pack
<b>K859902546A</b>	Break Glass Hammer with Chain
<b>K859902471A-BGRD</b>	Break Glass Faceplate, Red
<b>K859902471A-BGYL</b>	Break Glass Faceplate, Yellow
<b>K71400935A-01</b>	Faceplate Labels, White Text (Red Units)
<b>K71400935A-02</b>	Faceplate Labels, Black Text (Yellow Units)
<b>K71400701A</b>	Faceplate Label, EN54-11 Model
<b>K859901982A</b>	Lift Flap, No Label
<b>K859901982A-01</b>	Lift Flap with Label, IN CASE OF FIRE BREAK GLASS
<b>K859901982A-02</b>	Lift Flap with Label, TO ACTIVATE BREAK GLASS
<b>K859902467A</b>	Reset Keyway, 5-Pack
<b>K71400699A-01</b>	Bottom Actuation Label, White (Red Units)
<b>K71400699A-02</b>	Bottom Actuation Label, Black (Yellow Units)

### Push Button Call Points Replacement Parts

<b>K859902471A-PBRD</b>	Push Button Faceplate, Red
<b>K859902471A-PBYL</b>	Push Button Faceplate, Yellow
<b>K71400935A-01</b>	Faceplate Labels, White Text (Red Units)
<b>K71400935A-02</b>	Faceplate Labels, Black Text (Yellow Units)
<b>K859901982A</b>	Lift Flap, No Label
<b>K859901982A-03</b>	Lift Flap with Label, IN CASE OF FIRE PUSH BUTTON
<b>K859901982A-04</b>	Lift Flap with Label, TO ACTIVATE PUSH BUTTON
<b>K859902467A</b>	Reset Keyway, 5-Pack
<b>K71400699A-01</b>	Bottom Actuation Label, White (Red, Blue, Green and Black Units)
<b>K71400699A-02</b>	Bottom Actuation Label, Black (Yellow Units)

### Break Glass Call Points Optional Accessories

<b>K859901989A-0470</b>	EOL/Series Resistor Module, 470Ω
<b>K859901989A-1000</b>	EOL/Series Resistor Module, 1KΩ
<b>K859901989A-1800</b>	EOL/Series Resistor Module, 1.8KΩ
<b>K859901989A-2200</b>	EOL/Series Resistor Module, 2.2KΩ
<b>K859901989A-2400</b>	EOL/Series Resistor Module, 2.4KΩ
<b>K859901989A-3300</b>	EOL/Series Resistor Module, 3.3KΩ
<b>K859901989A-3600</b>	EOL/Series Resistor Module, 3.6KΩ
<b>K859901989A-4700</b>	EOL/Series Resistor Module, 4.7KΩ
<b>K859901989A-5600</b>	EOL/Series Resistor Module, 5.6KΩ
<b>K859901989A-10000</b>	EOL/Series Resistor Module, 10KΩ
<b>K859901989A-12000</b>	EOL/Series Resistor Module, 12KΩ

**Break Glass Call Points Optional Accessories (cont.)**

<b>K859901989A-15000</b>	EOL/Series Resistor Module, 15KΩ
<b>K859901989A-22000</b>	EOL/Series Resistor Module, 22KΩ
<b>K859901989A-33000</b>	EOL/Series Resistor Module, 33KΩ
<b>K859901989A-47000</b>	EOL/Series Resistor Module, 47KΩ
<b>K859901990A</b>	Supervisory Diode Module
<b>K859901982A</b>	Lift Flap, No Label
<b>K859901982A-01</b>	Lift Flap with Label, IN CASE OF FIRE BREAK GLASS
<b>K859901982A-02</b>	Lift Flap with Label, TO ACTIVATE BREAK GLASS
<b>K71400976A-01</b>	Stainless Steel Faceplate Label, FIRE
<b>K71400976A-02</b>	Stainless Steel Faceplate Label, EVAC
<b>K71400976A-03</b>	Stainless Steel Faceplate Label, BIOHAZARD ALARM
<b>K71400976A-04</b>	Stainless Steel Faceplate Label, GAS ALARM
<b>K71400976A-05</b>	Stainless Steel Faceplate Label, ESD
<b>K71400976A-06</b>	Stainless Steel Faceplate Label, "FIRE ALARM" (Dual Language English/Arabic)

**Push Button Call Points Optional Accessories**

<b>K859901989A-0470</b>	EOL/Series Resistor Module, 470Ω
<b>K859901989A-1000</b>	EOL/Series Resistor Module, 1KΩ
<b>K859901989A-1800</b>	EOL/Series Resistor Module, 1.8KΩ
<b>K859901989A-2200</b>	EOL/Series Resistor Module, 2.2KΩ
<b>K859901989A-2400</b>	EOL/Series Resistor Module, 2.4KΩ
<b>K859901989A-3300</b>	EOL/Series Resistor Module, 3.3KΩ
<b>K859901989A-3600</b>	EOL/Series Resistor Module, 3.6KΩ
<b>K859901989A-4700</b>	EOL/Series Resistor Module, 4.7KΩ
<b>K859901989A-5600</b>	EOL/Series Resistor Module, 5.6KΩ
<b>K859901989A-10000</b>	EOL/Series Resistor Module, 10KΩ
<b>K859901989A-12000</b>	EOL/Series Resistor Module, 12KΩ
<b>K859901989A-15000</b>	EOL/Series Resistor Module, 15KΩ
<b>K859901989A-22000</b>	EOL/Series Resistor Module, 22KΩ
<b>K859901989A-33000</b>	EOL/Series Resistor Module, 33KΩ
<b>K859901989A-47000</b>	EOL/Series Resistor Module, 47KΩ
<b>K859901990A</b>	Supervisory Diode Module
<b>K859901982A</b>	Lift Flap, No Label
<b>K859901982A-03</b>	Lift Flap with Label, IN CASE OF FIRE PUSH BUTTON
<b>K859901982A-04</b>	Lift Flap with Label, TO ACTIVATE PUSH BUTTON
<b>K71400976A-01</b>	Stainless Steel Faceplate Label, FIRE
<b>K71400976A-02</b>	Stainless Steel Faceplate Label, EVAC
<b>K71400976A-03</b>	Stainless Steel Faceplate Label, BIOHAZARD ALARM
<b>K71400976A-04</b>	Stainless Steel Faceplate Label, GAS ALARM
<b>K71400976A-05</b>	Stainless Steel Faceplate Label, ESD
<b>K71400976A-06</b>	Stainless Steel Faceplate Label, FIRE ALARM (Dual Language English/Arabic)