

#V-SBOX3

## VOSKER Steel Security Box

### Short Description

Protect your camera from burglars, animals, theft and environmental damage. Compatible with VOSKER V300 series security cameras.

### Long Description

This steel security box is an essential accessory to block access to your VOSKER V300 cameras. Made from premium-grade steel, it helps prevent vandalism and environmental damage. The multiple holes on any side make it easy to insert our cable lock or to use the front hole with a traditional lock.

### Features

- Weather-Resistant Heavy-Duty Steel
- Compatible with VOSKER cameras mounting arm
- Holes to anchor to any surface
- Holes on both sides to insert a cable-lock (#V-CB-LOCK)
- Hole in front to install a standard lock. Recommended lock size 3/8" (9mm).
- Removable front for easy access
- Compatible with VOSKER V300 series security cameras

### Recommended installation

Use with the VOSKER camera mounting arm to benefit from a fully adjustable positioning.

To insert the camera, simply remove the front panel and slide the camera in place. Then screw the mounting arm to the camera to secure it inside the security box.

Alternatively, the steel box can be mounted directly to a surface with screws.