




## Specifications

Part Number	TSP-2105	UPC: 816684004674	Barcode Scanner and Wiegand Converter Kit
		Scanner Part Number	CODE CR1100
Physical	Scanner	2.7 x 2.1 x 1.2 inches / 0.275 lbs. 67.5 x 52.5 x 29.7 mm / 13 Kg	
	Converter	4.5 x 2.9 x 0.94 inches / 0.3 lbs. 11.43 x 7.37 x 2.39 cm / 0.14 Kg	
Environmental	Storage Temperature	Converter	32°F to 158°F 0°C to 70°C
		Scanner	-22°F to 150°F -30°C to 65°C
	Operating Temperature	Converter	32°F to 158°F 0°C to 70°C
		Scanner	-4°F to 131°F -20°C to 55°C
	Enclosure	Converter	Extruded aluminum, not sealed or weather rated
		Scanner	Plastic housing
Electrical	Supply Voltage	Converter	8-16Vdc @ 300mA
		Scanner	5Vdc @ 350mA
5Vdc 1A wall-plug power supply for scanner is included.			
Scan Performance	Field Selection	High Density or Wide Field	
	Field of View	High Density: 30° horizontal by 20° vertical   Wide Field: 50° horizontal by 33.5° vertical	
	Focal Point	High Density: approx. 3.94" / 100 mm   Wide Field: approx. 4.53" / 115 mm	
	Optical Resolution	High Density: 960 x 640   Wide Field: 960 x 640	
	Pitch, Skew	± 65° (from front to back), ± 60° from plane parallel to symbol (side to side)	
	Rotational Tolerance	± 180°	
	Decode Capability	Standard 1D, PDF, 2D, Postal, and OCR symbologies.	
	Symbol Contrast	15% minimum reflectance difference	
Supported Symbologies	1D Symbologies	BC412, Codabar, Code 11, Code 32, Code 39, Code 93, Code 128, IATA 2 of 5, Interleaved 2 of 5, GS1 DataBar, Hong Kong 2 of 5, Matrix 2 of 5, MSO Plessey, NEC 2 of 5, Plessey, Straight 2 of 5, Telepen, Trioptic, UPC/EAN/JAN	
	Stacked 1D Symbologies	Codablock F, Code 49, GS1 Composite (CC-A/CC-B/CC-C), Micro PDF, PDF417	
	2D Symbologies	Aztec Code, Data Matrix, Data Matrix Rectangular Extension, Grid Matrix, Han Xin, Maxicode, Micro QR Code, QR Code, QR Model 1	
	Postal Codes	Australian Post, Canada Post, Intelligent Mail, Japan Post, KIX Code, Korea Post, Planet, Post-net, UK Royal Mail, UPU ID-tags	

# Cypress TSP-2105 Manual - Table of Contents

<b>Table of Contents</b>	
<b><i>Topic</i></b>	<b><i>Page</i></b>
Specifications	2
Converter Dimensions	4
Scanner Dimensions	5
Scanner Mounting Hole Pattern	6
Converter Pin Designations	7
Wiring Diagram	8
Scanner Configuration: Symbologies	9
Scanner Configuration: TSP Settings	10
Converter DIP Switches	11
Conversion Settings	12

# Cypress TSP-2105 Manual - Converter Dimensions



All dimensions are in inches.

# Cypress TSP-2105 Manual - Scanner Dimensions



Diagram above is from Code CR1100 User Manual (D032078 \_02 CR1100 User Manual).

# Cypress TSP-2105 Manual - Scanner Mounting Hole Pattern






Diagram above is from Code CR1100 User Manual (D032078 \_02 CR1100 User Manual).

# Cypress TSP-2105 Manual - Converter Pin Designations




The diagram above shows the pin designations for the three terminal blocks/headers on the converter unit.

# Cypress TSP-2105 Manual - Wiring Diagram



CODE CR1100 Barcode Scanner



# Cypress TSP-2105 Manual - Scanner Configuration: Symbologies

## Default Enabled Symbologies

Aztec  
Codabar  
Code 39  
Code 93  
Code 128  
Data Matrix  
Data Matrix Rectangle  
All GS1 DataBar  
Interleaved 2 of 5  
PDF417  
QR code  
UPC/EAN/JAN

## Default Disabled Symbologies

Codablock F  
Code 11  
Code 32  
Code 49  
Composite  
Grid Matrix  
Han Xin Code  
Hong Kong 2 of 5  
IATA 2 of 5  
Matrix 2 of 5  
Maxicode  
Micro PDF417  
MSI Plessey  
NEC 2 of 5  
Pharmacode  
Plessey  
Postal Codes  
Standard 2 of 5  
Telepen  
Trioptic

To enable or disable symbologies, scan the symbology barcodes located in the CR1100 Configuration Guide found on the product page at [codecorp.net](http://codecorp.net).

# Cypress TSP-2105 Manual - Scanner Configuration: TSP Settings

The CR1100 barcode scanner is configured with the three configuration QR codes to the right. They are scanned in order: A4, E4, C2.

The converter unit serial interface is configured for 9600 baud, the scanner baud rate must be configured to match. The last configuration QR code set the unit to scan barcodes automatically when one is presented.

**The scanner is preconfigured at the factory to work out of the box for typical applications.**

If the default configuration does not work for a specific application, see the configuration options in the CR1100 Configuration Guide found on the product page at [codecorp.net](http://codecorp.net).

Below is a test barcode. The default converter setting is Setting 65 (see table on page 12). This barcode should be output by the converter as a 26 bit (H10301) Wiegand read. The facility code value is 123, the card number value is 12345.

Test Barcode



M20112\_01

Reset to RS232 Factory Defaults M2

A4



M20163\_01

RS232 Interface - 9600 Baud Rate M2

E4



M20199\_01



Motion Detect Always On M2

C2

## Cypress TSP-2105 Manual - Converter DIP Switches

The converter included in the TSP-2105 supports many different conversion settings that are selectable with DIP switches on the converter board. The circuit board must be removed from the enclosure in order to access the DIP switches.

The picture below shows converter circuit board removed from the enclosure.



## Cypress TSP-2105 Manual - Conversion Settings

#	DIP SWITCH SETTING								INPUT		OUTPUT	
	1	2	3	4	5	6	7	8	Interface	Format	Interface	Format
31	X	X	X	X	X				Serial RS-232 9600 Baud TEST MODE			
32						X			Wiegand Output TEST MODE - 26 Bit, FC = 123, Card # = 4567			
57	X			X	X	X			RS-232 (9600)	12 Digit ASCII Dec	Wiegand	40 Bit Binary
58		X		X	X	X			RS-232 (9600)	16 Digit ASCII Dec	Wiegand	64 Bit Binary
65*	X						X		RS-232 (9600)	10 Digit ASCII Dec	Wiegand	26 Bit
68			X				X		RS-232 (9600)	12 Digit ASCII Hex	Wiegand	Variable
71	X	X	X				X		RS-232 (9600)	ASCII Dec	Wiegand	26 Bit
86		X	X		X		X		RS-232 (9600)	ASCII Dec	Wiegand	36 Bit
87	X	X	X		X		X		RS-232 (9600)	10 Digit ASCII Dec	Wiegand	37 Bit

\* Default converter setting.