

MINUTEMAN POWER TECHNOLOGIES
Encompass RTX Series
Product Specifications
1000VA – 3000VA
Single-phase Uninterruptible Power Supply

1.0 GENERAL

1.1 SUMMARY

This product specification will outline and define the electrical and mechanical features for a true double conversion, online, true sinewave, solid-state, uninterruptible power supply (UPS) system. The UPS shall provide high-quality, regulated AC power to sensitive electronic equipment connected to the system.

1.2 STANDARDS

The UPS shall be designed and manufactured in accordance with the applicable sections of the current revision of the following regulatory organizations codes. Where a conflict may arise between these standards made herein, the statements in this specification shall govern.

- FCC CFR Title 47, Part 15, Subpart B, Class A ANSI C63.4:2014 amended as per ANSI C63.4a:2017
- ISO 9001 & 14001
- cULUs (UL1778 5th Edition & CSA 22.2 no. 107.3-14 / R:2014)
- CE
- IEEE/ANSI EN62040-2:2006 Category C2, IEC61000-2-2:2002, IEC61000-4-2:2009, IEC61000-4-3:2006+A1:2008+A2:2010, IEC61000-4-4:2012, IEC61000-4-5:2014, IEC61000-4-6:2014, IEC61000-4-8:2010
- RoHS WEEE 2011/65/EU Directive
- EPA Energy Star 2.0
- Dept. of Energy DoE 10 CFR Part 430 Subpart B Appendix Y (for applicable models)

1.3 SYSTEM DESCRIPTION

1.3.1 Design Requirements:

A. Voltage – Input/output voltage specifications of the UPS shall be:

System Input: 55 – 150VAC single-phase, two-wire plus ground.
 System Output: 110, 120, 127VAC single-phase, two-wire plus ground.

- B. Output Load Capacity** – The specified output load capacity of the UPS shall range between 1000-3000VA with a 0.9 lagging power factor.

1.3.2 Design Requirements – Batteries

- A. Battery Cells:** Maintenance-free, sealed, non-spillable, lead acid, valve regulated.
- B. Reserve Time:** A minimum of 2 minutes at a full, measured load, with ambient temperature between 20° and 30° Celsius.
- C. Recharge Time:** Internal batteries to 90% capacity within eight hours after return of nominal AC power from low battery cut-off.

1.3.3 Modes of Operation – The UPS shall be designed to operate as a true online double conversion system in the following modes:

- A. Online Mode** – The critical AC load is supplied by the inverter power source. Any non-hazardous harmonics and/or anomalies are filtered through Power Factor Correction (PFC) circuitry. The internal batteries are simultaneously float-charging.
- B. On Battery Mode** – Upon failure or overvoltage of utility AC power, the connected AC load is supplied power by the UPS switching from the Online mode to the Battery mode while using the internal batteries. There shall be no interruption in power when switching from the Online mode to the Battery mode. When utility AC power returns, the UPS will return to Online mode with no interruption of power.
- C. Economy Mode** – When operating the UPS in Economy mode, the input utility power will bypass the inverter circuit and connect directly to the output of the UPS, powering the connected equipment while simultaneously charging the batteries. During a blackout, brownout or overvoltage event, the UPS will transfer to the On Battery mode, powering the connected equipment. When utility power returns or is at an acceptable level, the UPS will automatically transfer back to Economy mode and start recharging the batteries.
- D. Recharge Mode** – Upon restoration of AC utility power, after a utility AC power outage, the internal charger shall automatically start recharging the internal batteries.
- E. Bypass Modes** – Automatic Internal Bypass: Automatically activates when the UPS detects an internal hardware failure, battery failure or an overload.
- F. DC Cold Start Mode** – The UPS shall start and operate in the Battery Mode without AC utility power applied.

1.3.4 Performance Requirements

1.3.4.1 AC Input to UPS

- A. Wiring Configuration for Standard Units:** Single-phase, 2-wire plus ground.
- B. Voltage Range (Non-Battery mode):** 55 – 150VAC for all models
- C. Frequency:** Auto-Select 50/60Hz (+/- 6Hz.)
- D. Power Factor:** 0.9 lagging minimum at nominal input voltage and full rated UPS output load
- E. Input Protection:** All units will have a re-settable input circuit breaker to prevent excessive overload in AC mode, rated for the following:

- 1KVA/1.5KVA: 15 Amps
 - 2KVA: 30 Amps
 - 3KVA: 40 Amps
- F. Inrush Current:** 1KVA model – 27 Amps for 17ms
1.5KVA model – 43 Amps for 17ms
2KVA model – 57 Amps for 17ms
3KVA model – 78 Amps for 17ms
- G. Current Limit:** 1KVA model – 15 Amp input circuit breaker
1.5KVA model – 20 Amp input circuit breaker
2KVA model – 30 Amp input circuit breaker
3KVA model – 40 Amp input circuit breaker
- H. Surge Energy Rating:** All UPS shall use Metal Oxide Varistors for input surge protection, rated for the following:
- 1KVA: 140 joules
 - 1.5KVA: 254 joules
 - 2KVA: 254 joules
 - 3KVA: 254 joules
- I. Surge Protection:** All models will be capable of sustaining input surges without damage per: EN61000-4-5: 2KV
- J. Power Factor Correction (PFC):** 99% at nominal input voltage and full load
- K. Current Distortion:**
- Linear loads: Not to exceed 7% at full linear load and normal line voltage
 - Nonlinear loads: Not to exceed 10% at full nonlinear load and normal line voltage
- K. Voltage Transient Response:** 0nS – All modes
- L. Transient Recovery Time:** 60ms output voltage recovery to 90%
- M. Back-feed Protection:** All models will provide back-feed protection to utility power by providing an isolation relay at the input of the UPS.
- #### 1.3.4.2 AC Output, UPS Inverter
- A. Wiring Configuration:** Single-phase, 2-wire plus ground.
- B. Output Waveform:** True sine wave.
- C. Voltage Regulation:** Not to exceed $\pm 2\%$ until Low Battery Warning.
- D. Frequency:** Nominal Frequency 50/60Hz ± 0.2 Hz unless synchronized to the line.
- E. Voltage Distortion:**
- Linear loads: 3% at full-rated linear load
 - Nonlinear loads: 7% at full-rated nonlinear load
- F. Load Power Factor Range:** 1.0 - 0.9 lagging without de-rating.

- G. Step Load:** All models must be able to support a fifty percent rated load increase, with the batteries at a fifty percent charge, without dropping the connected loads.
- H. Output Power Rating:** Rated KVA at 0.9 lagging power factor for all models.
- I. Overload Capacity:** All Models will operate for the following durations based on the size of the overload:
- Online Mode: The UPS will transfer to Bypass mode after the listed time.
 - 105% of rated load – Continuous
 - 106% to 110% of rated load – 2 minutes
 - 111% to 125% of rated load – 1 minute
 - 126% to 150% of rated load – 30 seconds
 - > 150% of rated load – Immediate
 - Battery Mode: The UPS will shut down after the listed time
 - 105% of rated load – Continuous
 - 106% to 110% of rated load – 2 minutes
 - 111% to 125% of rated load – 1 minute
 - 126% to 150% of rated load – 30 seconds
 - > 150% of rated load – Immediate
 - Economy Mode: The UPS will transfer to Bypass mode after the listed time.
 - 105% of rated load – Continuous
 - 106% to 110% of rated load – 2 minutes
 - 111% to 125% of rated load – 1 minute
 - 126% to 150% of rated load – 30 seconds
 - > 150% of rated load – Immediate
- J. Inverter Output Adjustment:** 110, 120, 127VAC. Inverter output voltage adjustments must be performed via the LCD screen.
- K. Efficiency:** > 90% Full load in On Line mode (AC – AC)
> 97% Full load in Economy mode for models
- L. Dynamic Response:** $\pm 10\%$ at 100% load change in 60ms
- M. Transfer time:** 0ms from Online mode to On Battery mode
20ms from Economy mode to On Battery mode
- N. Crest Factor:** 3:1
- 1.3.5 UPS System Test** - The UPS must be able to perform an internal self-test of both the electronics and batteries, reporting any detected faults through Audio, Visual or software communication alarms. Self-tests must be performed through the following procedures:
- Power On: The UPS will power on when proper AC utility is available and the On/Test button is pressed and held until the UPS sounds one tone.
 - Front Panel: While the UPS is operating in Online mode the UPS can perform a self-test pressing and holding the Function button then pressing the Page UP button.
 - Software: The UPS can perform a self-test when accessed via a computer either through the power monitoring software or the optional SNMP card, (when properly installed).

1.3.6 Independent Battery Bypass – When the UPS is operating in Normal mode, and input utility power is within the nominal range of the UPS, it must be able to provide a filtered and a regulated output to connected loads with dead internal batteries or without internal batteries.

1.3.7 Output Load Shedding – All models will have output receptacles electrically wired into two independent circuits. The two circuits must have the ability to be individually controlled via management software and SNMP.

The 3KVA has a third circuit, which will be configured as Always On and can only be disabled when the output of the entire UPS is shut off.

1.3.6.1 Load Bank Configurations

1KVA/1.5KVA: Load Bank 1 – (3) NEMA 5-15R
Load Bank 2 – (3) NEMA 5-15R

2KVA: Load Bank 1 – (3) NEMA 5-15/20R
Load Bank 2 – (3) NEMA 5-15/20R

3KVA: Load Bank 1 – (3) NEMA 5-15/20R
Load Bank 2 – (3) NEMA 5-15/20R
Load Bank 3 – (1) NEMA L5-30R (Always On)

1.3.8 Current Monitoring – All units will have current monitoring circuitry on the UPS output receptacles to measure the combined total load of all the receptacles. This circuitry shall be used to calculate actual load.

1.4 ENVIRONMENTAL CONDITIONS

The UPS shall be able to withstand the following environmental conditions without damage or degradation of operating characteristics:

1.4.1 Operating Ambient Temperature: All models: 32°F to 104°F (0°C to +40°C).

1.4.2 Storage/Transport Ambient Temperatures: All models: 14°F to 122°F (-10°C to +50°C).

1.4.3 Relative Humidity: All models: 10 to 90% non-condensing.

1.4.4 Altitude: All models: Operating: 0 to +3,000 meters (0 to +10,000 feet).
All models: Storage/Transport: 0 to +15,000 meters (0 to +50,000 feet).

1.4.5 Audible Noise: Noise generated by the UPS under any condition of normal operation shall not exceed 55dBA when measured at 1 meter from the surface of the UPS:

1.5 SUBMITTALS

1.5.1 Proposal Submittals – Submittals with the proposal shall include:

- System configuration and description.
- Functional relationship of equipment including weights, and dimensions.
- Descriptions of equipment to be furnished, including deviations from these specifications.
- Size and weight of shipping units to be handled by installing contractor.

- 1.5.2 UPS Delivery Submittals** – Submittals upon UPS delivery shall include one (1) User’s manual that shall include a functional description of the equipment, safety precautions, instructions, operating procedures and battery replacement instructions.

1.6 WARRANTY

- 1.6.1 All Models** – The UPS manufacturer shall warrant all UPS models, including internal batteries, against defects in materials and workmanship for 36 months from purchase date or 42 months from date of manufacture, whichever period expires first.

1.7 QUALITY ASSURANCE

- 1.7.1 Manufacturer Qualifications** – A minimum of thirty year’s experience in the design, manufacture, and testing of solid-state UPS systems is required. The system shall be designed and manufactured according to world-class quality standards. All production manufacturing facilities shall be ISO9001 & ISO14001 certified.
- 1.7.2 Factory Testing** – Before shipment, the manufacturer shall fully and completely test the system to assure compliance with the specification.
- 1.7.3 Mean Time Between** – Failure The UPS shall have a mean time between failure, (excluding batteries), of 100,000 hours.

2.0 PRODUCT

2.1 FABRICATION

- 2.1.1 Materials** – All materials of the UPS shall be new, of current manufacture, high grade and free from all defects and shall not have been in prior service except as required during factory testing.

The maximum working voltage, current, and di/dt of all solid-state power components and electronic devices shall not exceed 90% of the ratings established by their manufacturer. The operating temperature of solid-state component sub-assembly shall not be greater than 90% of their ratings.

- 2.1.2 Wiring** - Wiring practices, materials and coding shall be in accordance with the requirements of the National Electrical Code (ANSI/NFPA 70).

- 2.1.3 Construction and Mounting** - The UPS enclosure shall be adaptable for standing vertically with appropriate mounting hardware supplied by the manufacturer of the UPS. The UPS enclosure can be mounted vertically on the floor using brackets supplied by the manufacturer. It shall also be capable of mounting within a 19” or 23” wide rack or cabinet structure with the appropriate mounting hardware supplied by the manufacturer.

The UPS shall be constructed of replaceable subassemblies. Any internal battery modules shall be replaceable by removing the front bezel and detaching the retaining bracket.

- 2.1.4 Physical Characteristics:**

A. Dimensions:

1KVA - Height: 3.5 in. (2U), Width: 18.9 in., Depth: 16.1 in.
1.5/2KVA - Height: 3.5 in. (2U), Width: 18.9 in., Depth: 19.1 in.
3KVA - Height: 3.5 in. (2U), Width: 18.9 in., Depth: 23.7 in.

B. Weights:

1KVA models:	24.3 lbs.
1.5KVA models:	44.1 lbs.
2KVA models:	44.1 lbs.
3KVA models:	59.5 lbs.

2.1.5 UPS Heat Dissipation:**A. AC Mode:**

1KVA models:	341 BTUs
1.5KVA models:	410 BTUs
2KVA models:	546 BTUs
3KVA models:	819 BTUs

B. Inverter Mode:

1KVA models:	338 BTUs
1.5KVA models:	461 BTUs
2KVA models:	491 BTUs
3KVA models:	1014 BTUs

2.1.6 Cooling – Cooling of the UPS shall be by forced air. High quality fans shall be used to minimize audible noise.

2.1.7 Grounding – The UPS chassis shall provide proper grounding to all output receptacles for reducing the risk of electrical shock hazard.

2.1.8 Input Power Connection – All UPS models shall come included with a power cord of no less than ten (10)-feet in length. The cord for all models will be connected to the UPS using a strain-relief assembly.

2.1.9 Input Power Plug/Connector – All UPS models must have a NEMA input plug, molded to the input power cord, rated to the following:

1KVA models:	NEMA 5-15P straight blade plug
1.5KVA models:	NEMA 5-15P straight blade plug
2KVA models:	NEMA 5-20P straight blade plug
3KVA models:	NEMA L5-30P locking plug

2.1.10 Output Power Receptacles

1KVA models:	6-Battery Backup/Surge (All NEMA 5-15R)
1.5KVA models:	6-Battery Backup/Surge (All NEMA 5-15R)
2KVA models:	6-Battery Backup/Surge (All NEMA 5-15/20R)
3KVA models:	7-Battery Backup/Surge (6-NEMA 5-15/20R / 1-NEMA L5-30R)

2.1.11 External Battery Pack Connector – All models will have a five (5)-pin Anderson connector, rated for 40 Amps, located on the back panel of the UPS, for exclusive use in attaching an external battery pack. The Anderson connector must be individually keyed to match the respective UPS model for which it is designated.

2.1.12 Network Surge Protection – All models will have two RJ45 connectors, located on the back panel, for input and output surge protection of a standard (10/100/1000 Base T) Ethernet network.

2.2 COMPONENTS

2.2.1 Charger

2.2.1.1 General - The term charger shall denote the solid-state equipment and controls necessary to convert incoming AC power to regulated DC power for battery charging. The charger will be battery independent and will operate regardless of battery voltage or installation. The charger shall be a single-stage, pulse-width modulated, switching-type charger with constant voltage/current limiting control circuitry.

2.2.1.2 Charge Modes – The charger will have two modes of operation, the standard charge mode and float charge mode.

- Standard mode: The charge voltage will be 0.125 times the Amp/hour rating of the internal batteries of the respective UPS

- Float mode: The charge voltage will be 0.0625 times the Amp/hour rating of the internal batteries of the respective UPS

2.2.1.3 DC Filter - The charger shall minimize ripple voltage into the battery. Under no conditions shall ripple voltage into the battery exceed 2% RMS. The charging circuitry shall be adequate to insure that the DC output of the charger will meet the input requirements of the Converter and DC/DC Booster circuits.

2.2.1.4 Automatic Restart - Upon restoration of utility AC power, after a utility AC power outage, the UPS shall automatically restart and resume the battery recharge mode.

2.2.1.5 Battery Recharge - The charger shall be capable of producing battery-charging current sufficient to replace 90% of the battery-discharged power within eight (8) hours. After the battery is recharged, the charger shall maintain the battery at full charge until the next emergency operation.

2.2.1.6 Overvoltage Protection - There shall be charger over-voltage protection so that if the charger voltage rises to the pre-set limit, the charger will turn off and issue a fault alarm.

2.2.2 Inverter

2.2.2.1 General - The term inverter shall denote the solid-state equipment and controls to convert DC power from the Converter or the DC/DC Booster circuits to regulated AC power for supporting the critical load.

2.2.2.2 Overload Capability - The inverter shall be capable of supplying current and voltage for overloads exceeding 111% and up to 150% of full load current at least thirty seconds. A status indicator and audible alarm shall indicate overload operation.

2.2.2.3 Fault Clearing and Current Limit - For currents of greater than 150% or for overload currents occurring for a time greater than the capability of the UPS, the inverter shall have electronic current-limiting protection to prevent damage to components. The inverter shall be self-protecting against any magnitude of connected output overload. Inverter control logic shall sense and disconnect the inverter from the critical AC load without the requirement to clear protective fuses.

2.2.2.4 Inverter Output Voltage Adjustment - The inverter shall have adjustable output voltages of 110, 120, 127VAC.

2.2.2.5 Fuse Failure Protection - Power semiconductors in the PFC and booster circuitry shall be fused so that loss of any one power semiconductor will not cause cascading failures.

2.2.2.6 Inverter DC Protection - The inverter shall be protected by the following disconnect levels:

- DC Overvoltage Shutdown
- DC Over-current Shutdown
- DC under-voltage Warning (Low Battery Reserve)
- DC under-voltage Shutdown (End of Discharge)

2.2.2.7 Over-discharge Protection - To prevent battery damage from over-discharging, the UPS control logic shall automatically turn off the inverter at a predetermined level as to not damage the batteries.

2.2.2.8 Output Frequency - The output frequency of the inverter shall be microprocessor controlled. The microprocessor shall regulate the inverter output frequency to +/- 0.1Hz for steady state and transient conditions. Total frequency deviation, including short time fluctuations and drift, shall not exceed 0.2Hz from the rated frequency unless synchronized to utility power.

2.2.3 Battery System

2.2.3.1 Hot-swappable - All units must have hot-swappable battery function. When the unit is operating in the AC Normal or Economy mode, the user must be able to replace the batteries without turning off the UPS.

2.2.3.2 Internal System Voltage - All models must have the internal batteries configured to support the following DC Bus voltages:

1KVA: 24VDC
1.5KVA/2KVA: 48VDC
3KVA: 72VDC

2.2.3.3 Approved Battery Manufacturers - The only approved battery manufacturers for use in the UPS or the optional external battery packs, are the following:

- B&B Battery
- China Storage Battery (CSB)
- YUASA Battery

2.2.4 Display and Controls

2.2.4.1 Monitoring and Control - The UPS shall be provided with a microprocessor-based unit status display and controls section designed for the convenient and reliable user operation. The UPS shall have a LCD display located on the front panel that provides the following information

A. LCD Icon Display - The LCD display panel will include dedicated display icons for the following information:

- AC Normal
- On Battery
- Overload

- Site-wiring Fault
- Fault Alarm
- Alarm Silenced

B. LCD Numeric Display - The LCD display will also have a real-time meter to display, in numeric fashion, the following data (Selection of the items can be made from the scroll button on the front panel) and the two Fault conditions:

- Input Voltage
- Input Frequency
- Output Voltage
- Output Frequency
- Output Current
- Connected Load Capacity (as a percentage)
- Battery Voltage
- Estimated runtime of connected loads (in minutes)
- Internal temperature of the UPS (in Celsius)

2.2.4.2 LED Displays – The UPS display panel will consist of five LED readouts denoting the following operations of the UPS:

- AC Present (Green): Illuminated when utility power is available. The LED is extinguished when the UPS operates in Battery Mode
- Load Bank 1 (Green): Illuminated when Load Bank 1 is active
- Load Bank 2 (Green): Illuminated when Load Bank 2 is active
- Bypass (Yellow): Illuminated when the UPS is in Bypass Mode
- Weak/Bad Battery (Red): Illuminated when the UPS detects a weak, bad or disconnected battery. The LED is extinguished if the battery condition of the UPS is satisfactory.

2.2.4.3 Controls - UPS operations shall be accomplished through the use of six front panel pushbutton controls.

- ON: Press and hold the button until the UPS beeps twice, (up to four seconds), to turn on the UPS. The button also silences the alarm when pressed while the UPS is in battery mode.
- OFF: Press and hold the button until the UPS beeps twice to turn off the UPS.
- Enter: Saves all configuration changes made to the UPS through front panel.
- Page Up: The Page Up button has split capabilities. It is used to changes to UPS settings and also can scroll up through a list of UPS settings or displays.
- Page Down: Scrolls down through a variety of UPS settings or displays.
- Function: By pressing and holding the Function button, then pressing the Page Up button will initiate a ten-second battery test.

2.2.4.4 Power Monitoring Software - The UPS shall be compatible with Power Monitoring Software to report important status information concerning the UPS and the utility power. The software must also be able to perform a graceful shutdown of connected loads prior to the shutdown of the UPS.

2.2.4.5 Communications Ports – The UPS will have one each of a RS232 and USB communication port. The ports will be used to communicate with the power monitoring software and will allow the user to configure, monitor and manage the

UPS. The RS232 and USB ports will be able to provide simultaneous communications.

A. RS232 – The RS232 communication port will be comprised of a 9-pin subminiature D-shell connector on the rear panel of the UPS for connecting a RS232 communication cable between the UPS and a computer for RS232 communications.

B. USB – The USB port will be HID-compliant and comprised of a USB 2.0 Type B connector for communications between the UPS and a computer.

2.2.4.6 Emergency Power Off (EPO) Port – The UPS shall have a 2-pin connector on the rear panel of the UPS for the exclusive purpose of providing a EPO communication port. The EPO port connects the UPS to a user-installed switch. In the Normal, Economy or On Battery mode, short pin1 to pin2 for approximately 0.5 seconds in order to shut down the UPS. In order to restart the UPS after enabling the EPO from AC or Economy mode, the UPS must be powered off and then back on via the ON and OFF buttons located on the front panel of the UPS. To restart the UPS from an EPO shutdown while in Battery mode, the ON button must be pressed once nominal utility power returns.

2.2.4.7 Alarm Messages – In addition to an audible alarm the following visual alarm messages shall be displayed via the LCD and LED displays located on the front panel:

- On Battery: While operating in the battery mode, the AC Present LED will turn off and the power flow icon will change to the battery mode power flow on the LCD panel. The alarm will sound once every 10 seconds until the unit reaches Low Battery Warning (LBW). The power flow icon will change to the AC mode power flow, the audible alarm will shut off and the AC Present LED will illuminate if utility power returns prior to Low Battery Cut-off (LBCO).
- Low Battery Warning: When the UPS reaches a Low Battery Warning, the LCD will display a specific Error Code for Low Battery Warning and the alarm will sound 2 beeps every 5 seconds until the unit reaches Low Battery Cut-off (LBCO).
- UPS Fault: When the UPS detects a hardware and/or internal fault, the UPS will sound a continuous alarm and the LCD panel will display a corresponding Error Code. Both the audible and visual alarms will remain on until the unit is shut down.
- Overload: When the UPS detects a connected load greater than 106% of the rated capacity of the UPS, a continuous alarm will sound the Overload Icon will illuminate with a corresponding Error Code. The alarm will remain on until the excess load is removed or the UPS self-protection circuit shuts down the UPS.
- Weak/Bad/Disconnected Battery: During a self-test, if the UPS detects a weak, bad or disconnected battery, the Weak/Bad Battery LED icon will illuminate, (Red), and the LCD panel will display the corresponding Error Code. The audible alarm will beep three times every five minutes until the batteries are recharged, reconnected or replaced or the UPS passes a subsequent self-test.
- Site Wiring Fault: If the UPS detects a faulty input ground or reversed polarity, the Site Wiring Icon on the LCD panel will illuminate with a respective Error Code. The displays will remain illuminated until the wiring faults are removed from the input.

2.2.4.8 Audible Alarm Silencer - When the unit is operating in Battery Mode, the audible alarm can be silenced when the ON button on the front display panel is pressed and released. Once the UPS reaches the Low Battery Warning stage, or a fault condition occurs, the alarm will reactivate and cannot be silenced. Once the UPS transfers to the AC mode the alarm will be reset to default.

2.2.5 Accessories (Optional)

2.2.5.1 SNMP Card - The UPS shall come equipped with an internal option card slot located on the backplane of the unit. This card slot can be used for the installation of a Simple Network Management Protocol (SNMP) card which will connect the UPS directly to an IP-based network using Ethernet communications. With the SNMP card properly installed and connected, the UPS will then become a managed device on a Local Area Network (LAN). The UPS shall be accessible over the network to all authorized individuals either through a Network Management System (NMS). Authorized individuals shall be able to monitor all aspects of the UPS operation, including important system measurements, alarm status, and alarm history data. Additionally, authorized users shall be able to execute battery tests, observe the results of such tests, and turn the UPS on and off via LAN. In the event of a utility failure, the SNMP card shall continue with live communications without the requirement of additional or separate UPS equipment until such time as the UPS shuts down for Low Battery Cut-Off. On resumption of utility power, the SNMP card shall automatically resume full communications over the LAN.

The optional SNMP card shall also be capable of HTTPs communications when SNMP management is not available or practical. Using most industry-standard web browsers as an interface, authorized users shall have access to all information available through the web interface.

Included with the optional SNMP Card will be SNMP Manager software. The software will be able to monitor and control (50-100) UPS, using installed SNMP cards, through a single management window on a networked computer platform.

2.2.5.2 Programmable Relay Card - A Programmable Relay Card shall be provided, as an option, to the UPS. The Programmable Relay Card is installed using the internal card slot in the UPS. When installed, the card will provide a configurable dry-contact closure communication port between the UPS and an attached device. A terminal block with a ground, common and six relay contacts are used for monitoring alarm events on the UPS to an attached device through a user-customized cable. The card is programmed using a Hyper-terminal application. An included feature will be the ability of the card to provide signals to Windows NT4/2000/XP/2003/7/8/10 for notification of power failure and low battery status on the connected UPS. Up to three computers may be configured for both the power failure and low battery status. Up to six computers may be configured for a single signal.

2.2.6 External Battery Packs (Optional) – The battery power pack shall include sealed, non-spillable, lead-acid, valve regulated battery cells housed in a separate cabinet that matches the UPS cabinet styling to form an integral system line-up. Each battery power pack shall be designed with the ability to be daisy chained to a maximum of ten from the UPS, for extended runtimes while operating in battery mode. Battery cells shall be mounted in metal cases designed to exactly match the width and height dimensions and installation of the control UPS. A battery disconnect circuit breaker shall be included for isolation of the battery pack from the UPS module. Brackets shall be provided for installation into a 19' rack or cabinet. Also, a set of stands shall be included for installation of the UPS in a

vertical format for use on a floor. The set of stands shall be of a design so as to interconnect with the control UPS to form a solid configuration.

2.2.6.2 Multiple Battery Pack Installations: Each battery pack shall be designed with the ability to be daisy-chained without an external battery pack charger.

2.2.6.3 UPS connector – The external battery pack will have a five (5) –pin Anderson connector, rated for 45 Amps, located on the back panel of the battery pack, for exclusive use in attaching to the UPS. The Anderson connector must be individually keyed to match the respective UPS model for which it is designated.

2.2.6.4 Daisy-chain Connector – The external battery pack will have a five (5) –pin Anderson connector, rated for 45 Amps, located on the back panel of the battery pack, for used for attaching to the UPS an additional battery pack, for the purpose of daisy-chaining to achieve extended runtime of connected loads. The Anderson connector must be individually keyed to match only the same type of battery pack used with the respective UPS.

2.2.6.5 DC Circuit Breaker

24-volt DC Battery Packs – 45 Amp

48-volt DC Battery Packs – 45 Amp

72-volt DC Battery Packs – 45 Amp

2.2.6.6 Construction and mounting – The battery pack enclosure shall be adaptable for standing vertically or mounting on a wall with appropriate mounting hardware supplied by the manufacturer. The battery pack enclosure can be mounted horizontally on the floor using brackets supplied by the manufacturer. It shall also be capable of mounting within a 19” or 23” wide rack or cabinet structure with the appropriate mounting hardware supplied by the manufacturer.

The battery pack shall be constructed of replaceable battery module assemblies. Any internal battery modules shall be replaceable by removing the front bezel and detaching the retaining bracket.

3.0 Manufacturer’s Warranty and Service

3.1 Manufacturer’s Warranty Procedure

Within the first thirty-six (36) months of purchase or forty-two months from date of manufacture, whichever occurs first, any defect or malfunction of the UPS device shall require contact with the manufacturer for diagnosis. If required, the manufacturer will provide the customer with a Return Materials Authorization, (RMA), number to send the defective product to the factory for repair or replacement, at the discretion of the manufacturer. It will be the responsibility of the customer to provide transportation of the unit to the factory. Once repaired, or replaced, the manufacturer will incur ground freight expense to return the product to the customer.