



Esprit Compact Operations Manual



Document number: C6720M

Publication date: 02/24

Table of Contents

Introduction	4
System Requirements	4
Accessing Camera Settings	5
Accessing the Camera Web Interface	5
Creating the Initial User	5
Logging In	5
Logging Out	6
Using the Live View	7
Navigating Through the Web Interface	7
Using the Camera Zoom and Focus Controls	7
Activating the Camera Washing Sequence	7
Viewing a Camera Tour	7
Using Camera Presets	8
Adding a Camera Preset	8
Moving the Camera to a Preset Position	8
Deleting a Preset	8
Using the PTZ Camera Controls	8
Setting and Navigating to the Camera	8
Saving a Still Image	8
Configuring the System Settings	10
Configuring General Settings	10
Managing the Camera Firmware	11
Configuring Storage Management	11
Enabling Onboard Storage	11
Downloading Recorded Video from the Web Interface	12
Downloading Recorded Video from the SD Card	12
Deleting Recorded Video	13
Extended Settings	13
Configuring Diagnostics	13
Configuring the Network and Security Settings	15
Configuring the Network Settings	15
Enabling SRTP Streaming	17
Modifying Security Settings	17
Configuring the Users	18
Adding a User	18
Modifying Users and Passwords	18
Removing a User	18
Keeping Usernames and Passwords After Firmware Revert	19
Configuring 802.1x Port-Based Authentication	19

Esprit Compact Operations Manual

Configuring the 802.1X Port Security	19
Switching 802.1X Authentication Profiles	20
Removing an 802.1X Authentication Profile	20
Returning to the Network Page	20
Configuring SNMP	20
Configuring the IP Filter	21
Managing Certificates	23
Downloading Certificates	23
Removing Certificates	23
Downloading Certificate Signing Requests	23
Uploading Certificates	23
Uploading CA Certificates	24
Configuring Imaging	25
Configuring General Imaging Settings	25
Understanding Backlight Compensation (BLC) and Wide Dynamic Range (WDR)	29
Adjusting White Balance Settings	29
Using Window Blanking	31
Setting a Window Blank	31
Deleting a Window Blank	31
Configuring PTZ Settings	32
Creating PTZ Tours	32
Editing PTZ Tours	32
Defining PTZ Limit Stops	33
Configuring the Camera Washer	33
Setting up PTZ Compass	34
Configuring A/V Streams	35
Compression and Image Rate	35
Enabling and Configuring Smart Compression	36
Viewing the RTSP Stream URI	36
Accessing the Still Image URI	37
Saving or Restoring Video Configurations	37
Configuring Smart Compression Advanced Settings	37
Configuring Events	38
Configuring Motion Detection	38
Analytics Configuration	38
Configuring Digital Inputs and Outputs	39

Introduction

Before you access the web interface, make sure all the procedures described in the camera installation guide have been completed.



Note: Features and options are disabled if they are not supported by the camera.

System Requirements

The web interface can be accessed from any Windows, Mac, or mobile device using one of the following browsers:

- Mozilla Firefox
- Google Chrome™



Note: The web interface may work with older or unsupported browsers, but this has not been tested.

Accessing Camera Settings

Use the Motorola Camera Configuration Tool (CCT) <https://www.pelco.com/camera-configuration-tool/> or the camera web user interface to access camera settings.



Note: Smart Analytics configuration requires the CCT.

Accessing the Camera Web Interface

After the camera has been installed, use the camera's IP address to access the web interface. The IP address can be found in the Motorola Camera Configuration Tool (CCT) — Click the **Network** tab to see the details of the selected cameras.

After you identify the IP address, complete the following procedure to access the web interface:



Note: The web browser must be configured to accept cookies or the camera web interface will not function correctly.

1. On a computer with access to the same network as the camera, enter the camera's IP address into a web browser in the format `http://<camera IP address>/`
For example: `http://192.168.1.40/`
2. You will automatically be prompted to enter your username and password to access the camera. You will be asked to create a user with administrator privileges before the device will be operational. For more information, see [Adding a User](#).

Creating the Initial User

Cameras do not have a default username and password and will be in a factory default state.



Caution: You must create a user with administrator privileges before the camera is operational.

If the camera is in the factory default state, you will be redirected to the New User page to create an administrator user:

1. Enter a new User Name or keep the default `administrator` name.
2. Enter a new Password for the user. It is recommended to use a secure and complex password.
3. Confirm the new password.
4. For the first user, Administrator must be selected in the Security Group drop-down menu.
5. Click Apply. After creating the user, you will be asked to login.

Logging In

You will automatically be prompted to enter your username and password to access the camera.

- If the camera is in the factory default state, you will be asked to create a user with administrator privileges before the camera will be operational. Use these credentials when logging in.



Note: Pelco recommends that you add a password after your first login. For more information, see [Modifying Users and Passwords](#).

Logging Out

To log out of the camera, at the upper right corner of the window, click **Logout**.



Note: After 15 minutes of inactivity, the Web UI will automatically log the user out.

Using the Live View

After you log in, the first page you see is the *Live View*. The *Live View* contains an image panel that displays the live video stream.

Navigating Through the Web Interface

Use the tabs at the top of the window to navigate through the web interface. Click the **Live View** tab at any time to return to this page.

The following sections describe the buttons that are displayed under the image panel if users have access to Pan-Tilt-Zoom (PTZ) controls. PTZ controls allow users to control the zoom, focus, and positioning of a camera. To give a user PTZ controls, see [Adding a User](#).

Using the Camera Zoom and Focus Controls

Camera Zoom and Focus controls are at the lower left of the application.

- To zoom out, move the slider towards the left.
- To zoom in, move the slider towards the right.
- To focus towards zero:
 - Click << to take a large step.
 - Click < to take a small step.
 - Click **0** to focus at zero.
- To focus towards infinity:
 - Click >> to take a large step.
 - Click > to take a small step.
 - Click **Inf** to focus at infinity.
- If the camera supports auto focusing, click **Auto Focus**.

Activating the Camera Washing Sequence

The Pelco Esprit Compact camera offers optional wiper and washer components to clean the glass surface. The washing sequence can be started by clicking **Washer Sequence** at the lower left of the application window. There is also an option to perform a single wipe which can be started by clicking **Single Wipe**. This might cause the camera's tilt position to move temporarily, the position will be restored after the wipe action is finished.



Note: The camera also report on low water levels for the washing tank. The optional sensor can be configured by attaching it to the digital input. In order for the washer to work correctly, the washer circuit must be connected to Digital Output 1 with the Circuit State set to Normally Open. For more information, see [Configuring Digital Inputs and Outputs](#).

Viewing a Camera Tour

Users can start and stop a PTZ camera Tour on the *Live View* page.

To create a tour, see the section titled [Creating PTZ Tours](#). The tours can also be configured in the client software through the PTZ controls.

To view a tour:

Esprit Compact Operations Manual

1. At the lower-right of the Live View page, use the drop-down menu to select the name of a tour in the *Tours* field.
2. Click **Start** to start the tour.
3. You can pause a tour at any time just by using the other PTZ controls. See the section titled *Using the PTZ Camera Controls*.
4. Click **Stop** to end the tour.

Using Camera Presets

Users can save frequently used pan, tilt, zoom, and focus configurations as presets on the Live View page.

The presets can also be configured in the Client software.

Adding a Camera Preset

1. On the Live View page, use the Pan, Tilt, Zoom, and Focus controls to focus the camera on a specific point in the video image.
2. Enter a name in the **Add Preset** field, and then click **Add**.

Moving the Camera to a Preset Position

To use a preset, select a configured preset from the **Presets** drop-down menu, and then click **Go**.

Deleting a Preset

To delete a preset, select a preset from the drop-down menu, and then click **Remove**.

Using the PTZ Camera Controls

1. To zoom the camera:
 - Besides using the Zoom slider, you can also click and drag to create a green box on the image panel to define the area you want to zoom in to see.
2. To move the camera:
 - Click anywhere on the image panel to center the camera to that point.
 - Click and drag your mouse from the center to move the camera in that direction. The farther the arrow is from center, the faster the camera will move.

Setting and Navigating to the Camera

1. Click the **Live View** tab.
2. To set a new Home position:
 - a. Use the instructions in the sections titled *Using the Camera Zoom and Focus Controls* and *Using the PTZ Camera Controls* to choose the position that will be set to Home.
 - b. At the lower-right of the Live View page, to the right of *Home*, click **Set**.
3. To return to the Home position, to the right of *Home*, click **Go**.

Saving a Still Image

To use this feature, the following settings are required for the camera:

Esprit Compact Operations Manual

- There is an SD card inserted in the camera. For more information, see the camera's installation guide.
- The camera's onboard storage settings are enabled on the *Storage Management* page. For more information, see [Configuring Storage Management](#).
- The camera's video format must be set to MJPEG in the *Video Configurations* page. For more information, see [Compression and Image Rate](#).

After all the requirements have been met, you can click **Save Still to SD Card** and the image that is displayed in the Live View page is automatically saved to the SD card.

If the requirements are not met, **Save Still to SD Card** is disabled, and *Storage Status* will provide failure information.


To download the snapshot, see [Compression and Image Rate](#).

Configuring the System Settings

Use the *System* tab to configuring *General Settings*, *Firmware*, *Storage Management*, and *Diagnostics*.

Configuring General Settings

The *General Settings* page allows you to set the camera's identity.

1. Click the **System** tab, and then click the **General Settings** button.
 2. In the *Name* field, give the camera a meaningful name.
 3. In the *Location* field, describe the camera's location.
 4. From the *Mode* drop-down menu, select the mode in which the camera will operate.
 - **Full Feature** — This is the standard operating mode that offers the full functionality of the camera.
 - **High Framerate** — This mode will use the maximum image rate possible but will disable Analytics in order to achieve the maximum frame rate. WDR can be enabled up to 30 fps and should be disabled for frame rates higher than 30 fps.
 5. Select the *Lens Distortion Correction* checkbox to turn lens distortion correction on or off. Enabling this option helps attenuate the barrel distortion effect caused by wide-angle lenses. Applying this configuration will enable lens distortion correction for all camera heads and the camera will reboot in the process.
 6. Select any of the *Overlay Settings* checkboxes to display and stamp that information on the camera's video stream. The options are:
 - **Display Date**—Selecting the *Display Date* checkbox also enables the *Date Format* drop-down menu. From the list, choose the date format.
 - **Display Time**
 - **Display GMT Offset**
 - **Display Name**
 - **Display Location**
 7. In the *Time Settings* area, select how the camera keeps time.
 - To manually set the camera's date and time, enter the time zone on this page.
 - Select the *Automatically adjust clock for Daylight Savings Time* checkbox, if required.
 - To auto-synchronize the camera's date and time with an NTP server, configure the NTP server on the *Network and Security* tab, *Network* page. See the section titled [Configuring the Network Settings](#).
-  **Caution:** The time setting must always be current. To ensure that the time is always current you should do one of the following:
- Set up NTP on the DHCP server, if your VMS supports this feature.
 - Use a valid public NTP server.
 - Manually set the correct time in the Time Settings fields.
8. Click **Apply** to save the settings.

Managing the Camera Firmware

The *Firmware* page provides the current firmware version. From this page, you can also manually upgrade the firmware, reboot the device, and restore to the factory defaults.

- To manually upgrade the camera firmware:
 1. Download the latest version of the firmware .bin file from the Pelco website (www.pelco.com/training-support/).
 2. Click the **System** tab, and then click the **Firmware** button.
 3. Click **Choose File**, and then browse to and locate the downloaded firmware file.
 4. Click **Upgrade**. Wait until the camera upgrade is complete.
- To reboot the camera, in the *Reboot Device* area, click **Reboot**.
- To restore the camera to factory defaults, but preserve Network settings, in the *Restore to Factory Defaults* area, select the *Soft Reset* checkbox.
- To restore the camera to factory defaults, in the *Restore to Factory Defaults* area, click **Restore**.

Configuring Storage Management

On the *Storage Management* page, you can enable the camera's onboard storage feature and download recorded video directly from the camera.



Note: For cameras with 2 microSD card slots, you can now use one or both SD card slots. The camera will record video to both SD card slots simultaneously if two SD cards are inserted. The total storage capacity of the system is the combined storage capacity of each of the individual cards. The second microSD card slot is reserved for future use.



Note: You can now use one or both SD card slots. The camera will record video to both SD card slots simultaneously if two SD cards are inserted. The total storage capacity of the system is the combined storage capacity of each of the individual cards.

To access the *Storage Management* page, click the **System** tab, and then click the **Storage Management** button.

Current information about the camera is presented in the *Device Information* section at the top of the page. It includes *Status*, *Total Capacity*, *Current Usage*, *Remaining Capacity*.

Enabling Onboard Storage

To use the camera's onboard storage feature, you must first insert an SD card into the camera. Refer to the camera's installation manual for the location of the SD card slot.

The SD card will record from the camera's highest resolution, non-tiled stream. In most cases, this will be the primary stream.



Note: For cameras with 2 microSD card slots, you will only be able to configure the microSD card that is inserted first, in either card slot. The second microSD card slot is reserved for future features.

1. Click the **System** tab, and then click the **Storage Management** button.
2. In the **Settings** area, click to select the **Enable Onboard Storage** checkbox.
3. By default, the camera is set to only record to the SD card when it is unable to communicate with the network video management server. If you prefer to have the camera record video to both the

network video management server and to the SD card, click to deselect the checkbox for the **Record only when server connection is interrupted** to disable the setting.

4. Select one of the following recording modes:
 - **Continuous:** the camera never stops recording to the SD card.
 - **On Motion:** the camera only records when there is motion in the scene.
If you are configuring a Pelco video analytics camera, the On Motion setting will record either pixel change in the scene or analytics motion events depending on how the camera is configured.

The recorded video will be divided into files no more than five minutes in length or 100 MB in size.

5. On the *Video Configurations* page, make sure the format is set to H.264 or H.265 to maximize the SD card recording capacity and performance. See the section titled [Compression and Image Rate](#).

Downloading Recorded Video from the Web Interface

Listed in the *Recordings* section are all the videos that have been recorded to the SD card.

If you are using a CryptR micro card in the camera SD slot for FIPS level 3 encryption, you will not be able to use onboard storage in the SD card slot. For cameras with 2 microSD slots you can only use the slots for either storage or the CryptR micro card, both options cannot be used at the same time.

It is recommended that you download recorded video from the web interface. However, if your bandwidth is limited, you can choose to download the recorded video directly from the SD card. For more information, see [Downloading Recorded Video from the SD Card](#).

To download recorded video from the web interface, perform the following:

1. Click the **System** tab, and then click the **Storage Management** button.
2. In the *Recordings* area, click to select the checkbox beside all the videos you want to download.
To help you find the video you want, filter the videos by date and time. Click to select the checkbox for **Filter**, type in the dates in the *From* and *To* fields, and then select the *From* and *To* time range.
3. Click **Download**.

The selected video files are automatically downloaded to your browser's default *Downloads* folder. If you are prompted by the browser, allow the download to occur.



Note: Do not close your browser window until the download is complete or the file might not download correctly. This is important if you are downloading multiple video files because the files are downloaded one by one.

Downloading Recorded Video from the SD Card

If you do not have enough bandwidth to download recorded video directly from the web interface, you can choose to download the recorded video directly from the SD card.

To download recorded video directly from the SD card:

1. Click the **System** tab, and then click the **Storage Management** button.
2. In the **Settings** area, click to deselect the **Enable Onboard Storage** checkbox, and then click **Apply**.
3. Remove the SD card from the camera.
4. Insert the SD card into a card reader.

5. When the *Windows AutoPlay* dialog box appears, select **Open folder to view files**.
6. To download all the recorded videos, click **Download All**; to download specific video, select the video files you want then click **Download Selected**.
7. When you are prompted, choose a location to save the video files.
The files start downloading from the SD card and are saved to the selected location.
8. When you are ready, eject the SD card.
9. Insert the SD card back into the camera then click to select the checkbox for Enable Onboard Storage to begin recording to the SD card again.


Deleting Recorded Video

As the SD card becomes full, the camera automatically starts overwriting the oldest recorded video. You can also choose to manually delete video to make room for new recordings.

1. Click the **System** tab, and then click the **Storage Management** button.
2. Delete video by one of the following methods:
 - To delete individual video files, in the *Recordings* section, select all of the files you want to delete from the *Recordings* list, click **Delete**, and then click **OK** in the confirmation dialog box.
 - To delete all of the recorded video files, in the *Onboard Storage* section, click **Format Card** to format the SD card, and then click **OK** in the confirmation dialog box.

Extended Settings

On the Extended Settings page, you can configure ONVIF Settings.

1. Select the **Enable Multi-Packet XML Documents** checkbox to enable multi-packet XML documents to reduce metadata size. Only for Video Management systems that support multi-packet XML documents.
 **Important:** you must enable multi-packet XML when connecting to VideoXpert to ensure that bounding boxes align with their targets.
2. Select the **Enable Analytics Options Requests** checkbox to enable the `GetAnalyticsModuleOptions` and `GetRuleOptions` Requests.
3. Select the **Enable Analytics XML Metadata** checkbox to send analytics metadata in the XML metadata stream.
4. Select the **Enable Run-Length Encoding of Motion Mask** checkbox to enable run-length encoding of the motion mask. Only for Video Management Systems that do not require an un-encoded mask.
5. Select the **Enable Supplemental Events** checkbox to send supplemental events not defined by ONVIF that may be useful to some Video Management Systems.
6. Select the **Enable Singleton Analytics Events** checkbox to send singleton Analytics events instead of property events.
7. Click **Apply** to save your changes.

Configuring Diagnostics

The *Device Log* page allows you to view the camera system logs and the camera access logs.

Esprit Compact Operations Manual

1. Click the **System** tab, and then click the **Diagnostics** button.
2. In the **Type** drop-down menu, select one of the following:
 - **Access Logs** — Logs of users who have logged into the web interface.
 - **System Logs** — Logs of camera operations.
3. In the **Minimum Log Level** drop-down menu, select the minimum level of log message you want to see:
 - **Error** — Sent when the camera encounters a serious error. These are the highest level log messages.
 - **Warning** — Sent when the camera encounters a minor error such as an invalid username and password.
 - **Info** — Status information sent by the camera. These are the lowest level log messages.
4. In the **Maximum Number of Logs** drop-down menu, select the number of log messages you want displayed.
5. Click **Update**.



Note: There is also a Filter field with text that you can enter to search against.

The logs update to display the filtered information. The most recent log event is always displayed first.

Configuring the Network and Security Settings

Use the *Network and Security* tab to configure the *Network*, *Security*, *Users*, *802.1X*, *SNMP*, *DSCP*, and *IP Filter* settings.

Configuring the Network Settings

On the *Network* page, you can change how the camera connects to the server network and choose how the camera keeps time.




Note: You can only set the HTTPS port, the RTSP port, and the NTP Server in the camera web interface.

1. Click the **Network and Security** tab, and then click the **Network** button.
2. At the top of the page, select how the camera obtains an IP address:
 - **Obtain an IP address automatically:** select this option to connect to the network through an automatically assigned IP address.
The IP address is obtained from a DHCP server. If it cannot obtain an address, the IP address will default to addresses in the 169.254.x.x range.
 - **Use the following IP address:** select this option to manually assign a static IP address.
 - **IP Address:** Enter the IP Address to use.
 - **Subnet Mask:** Enter the Subnet Mask to use.
 - **Default Gateway:** Enter the Default Gateway to use.
3. Click to select the checkbox for **Disable setting static IP address through ARP/Ping method** to disable the ARP/Ping method of setting an IP address.
4. In the *IPv6 Settings* area, click to select the checkbox for *Enable IPv6*, and then configure the following settings.



Note: Enabling IPv6 does not disable IPv4 settings.

- a. Click to select the checkbox for **Accept Router Advertisements** if using Stateless Address Auto-Configuration.
- b. From the **DHCPv6 State** drop-down menu, select one of the following:
 - **Auto:** DHCPv6 state is determined by router advertisements (RA).
 **Note:** The Accept Router Advertisements setting must be enabled for this setting to perform as expected.
 - **Stateless:** the camera only receives DNS and NTP information from the DHCPv6 server. It does not accept an IP address from the DHCPv6 server.
 - **Stateful:** the camera receives IP address, DNS and NTP information from the DHCPv6 server.
 - **Off:** the camera does not communicate with the DHCPv6 server.
- c. In the **Static IPv6 Addresses** field, enter the preferred IPv6 address. Click the add icon (+) to add another address.

To change the prefix length, enter the preferred IPv6 address using Classless Inter-Domain Routing (CIDR) notation. For example, `2001:db8::1/32` would indicate the address prefix is 32-bits long.

By default, the prefix length is set to `/64`.



Note: The configured prefix length might not display correctly in the web interface, but the prefix used by the camera will be the configured length.

- d. In the *Default Gateway* field, type the default gateway you prefer to use. You can only assign a default gateway if RA is disabled.

The IPv6 addresses that can be used to access the camera are listed under the *Current IPv6 Addresses* area.

5. To customize the hostname, enter it in the *Network Hostname* field.
6. In the *DNS Lookup* area, select how the camera will obtain a Domain Name System (DNS) server address.
 - Click to select the checkbox for *Obtain DNS server address automatically* to automatically find a DNS server.
 - Click to select the checkbox for *Use the following DNS server addresses* to manually set DNS server addresses. You can set up to three addresses:
 - In the *Preferred DNS server* field, type the address of the preferred DNS server.
 - (Optional) In the *Alternate DNS server 1* field, type the address of an alternate DNS server. If the preferred server is not available, the camera will attempt to connect to this server.
 - (Optional) In the *Alternate DNS server 2* field, type the address of another alternate DNS server. If both the preferred server and the first alternate server are unavailable, the camera will attempt to connect to this server.
7. In the Port Settings area, specify which control ports are used to access the camera. You can enter any port number between 1 and 65534. The default port numbers are:
 - *HTTP Port: 80*
 - *HTTPS Port: 443*
 - *RTSP Port: 554*
 - *RTSP Replay Port: 555*

To limit camera access to secure connections only, click to deselect the checkbox for *Enable HTTP connections*. HTTP Port access is enabled by default.

8. In the NTP Server area, select the checkbox for how the server is configured—*DHCP* or *Manual*. If you select *Manual*, type the server address in the *NTP Server* field.
9. In the MTU area, set the Maximum Transmission Unit (MTU) size in bytes. Type a number in the *MTU size* field that is within the available range displayed on the right. Lower the MTU size if your network connection is slow.
10. In the *Settings* area, click to select an option from the Speed & Duplex drop-down menu. The Auto-negotiation (default) setting is the preferred setting for most cameras, and will negotiate the optimal speed and duplex setting for your network connection.

11. In the Security area, click to select from the drop-down menu the Minimum TLS version that the camera should to encrypt the communication between camera and server, and to block older TLS versions that should not be used.
12. PTZ Priority Mode is a feature that improves video latency by disabling network traffic shaping. Video latency is higher when network traffic shaping is enabled and packets are delayed to reduce network traffic spikes. Set the Priority Mode that best suits your system:



Note: Network traffic spikes might result in packet loss.

- **Controlled (Default).** This default option will allow your system to control the PTZ priority mode. When an Client has the PTZ controls selected, PTZ priority mode will be enabled.
- **Enabled.** Select this option to override Client control and set PTZ priority mode to always be enabled. Select this option to improve video latency.
- **Disabled.** Select this option to override Client control and set PTZ priority mode to always be disabled. Select this option to use network traffic shaping to reduce traffic spikes.

13. Click **Apply** to save the settings.

Enabling SRTP Streaming

SRTP streaming allows the camera to stream via SRTP encryption to Video Management Systems that also support SRTP. To enable SRTP streaming, the camera must have the correct firmware installed.



Note: Using SRTP for third-party integrations may require additional steps. For information on configuring SRTP streaming when using third-party integrations, refer to the manufacturer's documentation.

Requirements

- SRTP streaming requires an HTTP connection.
You can enable HTTP connections in your camera's web interface. For instructions, see [Configuring the Network Settings](#).
- SRTP streaming requires an OpenSSL library connection and does not work with FIPS 140-2 or NXP TPM.
You can change the encryption engine to use OpenSSL on the Security page in your camera's web interface. For instructions, see [Modifying Security Settings](#).
- SRTP streaming requires a Unicast and Multicast over UDP connection.

Modifying Security Settings

1. Click the **Network and Security** tab, and then click the **Security** button.
2. In the **Encryption Engine** drop-down list, select the type of encryption to use.
 - Open SSL is the default option for encryption.
 - FIPS 140-2 enables FIPS 140-2 level 1 encryption.
3. Click **Apply** to save the settings.



Note: FIPS 140-2 Level 1 requires the purchase of a FIPS camera license.



Caution: Changing this setting on your camera will require your camera to reboot and you will lose the video stream for that time. Pelco recommends that you apply this setting during non-critical operating times.

Configuring the Users

On the *Users* page, you can add new users, modify existing users, and remove users.

Adding a User

1. Click the **Network and Security** tab, and then click the **Users** button.
2. Click **Add...**
3. On the *Add User* page, enter a *User Name* and *Password* for the new user.
4. In the *Security Group* drop-down menu, select the access permissions available to this new user.
 - The **User** has access to the Live View and optional PTZ controls, but cannot access any of the setup pages. To enable the PTZ controls, click to select the checkbox for *Use PTZ Controls*.
 - The **Operator** has access to the Live View but limited access to the setup features. The user can access the *General Settings* page, *Imaging* page, *Video Configurations* page, *Motion Detection* page, *Window Blanking* page, and the *Digital Inputs and Outputs* page. The new user can also configure onboard storage settings but cannot delete video recordings or format the SD card.
 - The **Administrator** has full access to all the available features in the camera web interface, including PTZ controls.
5. Click **Apply** to add the user.

Modifying Users and Passwords

1. Click the **Network and Security** tab, and then click the **Users** button.
2. Click to select a user from the *User Name (Security Group)*, and then click **Modify**.
3. To change the user's password, enter a new password for the user.
4. To change the user's security group, select a different group from the **Security Group** drop-down menu.



Note: You cannot change the security group for the administrator account.

5. To enable the PTZ controls for the *User* security group, click to select the checkbox for *Use PTZ Controls*
6. Click **Apply** to save the settings.

Removing a User



Note: You cannot remove the default Administrator user.

1. Click the **Network and Security** tab, and then click the **Users** button.
2. Click to select a user from the *User Name (Security Group)*, and then click **Remove**.



Caution: There is no confirmation dialog box. The user is removed immediately.

Keeping Usernames and Passwords After Firmware Revert

To add a layer of security to protect the camera from theft, you have the option of keeping the camera's current usernames and passwords after a firmware revert.



Caution: If you have set your camera to use FIPS 140-2 encryption, we recommend that you do not choose to keep usernames and passwords after a firmware revert. The password and username is not stored in a FIPS 140-2 compliant manner and may affect your FIPS 140-2 compliance.

Normally if you restore the camera firmware back to the factory default settings, the camera returns to using the default username and password. When you enable this feature, the camera will continue to use the configured username and passwords, so the camera cannot connect to new servers without the appropriate credentials.



Caution: Forgetting your own username or password after enabling this setting voids your warranty. The primary method of restoring the factory default username and password will be disabled.

1. Click the **Network and Security** tab, and then click the **Users** button.
2. At the bottom of the Users page, click to select the checkbox for **Do not clear usernames or passwords on firmware revert**.
3. After you select the checkbox, the following popup message appears:

Please store your administrator password in a safe place. Password recovery is not covered by warranty and loss of password voids your warranty.

4. Click **OK** if you agree to the feature limitations.

Always keep a copy of your password in a safe place to avoid losing access to your camera.

Configuring 802.1x Port-Based Authentication

If your network switch requires 802.1x port-based authentication, you can set up the appropriate camera credentials so that the video stream is not blocked by the switch. You can configure multiple profiles (Saved 802.1x Configurations); but be aware that you can only enable one profile at a time.

Configuring the 802.1X Port Security

1. Click the **Network and Security** tab, and then click the **802.1x** button.
2. From the *EAP Method* drop-down menu, select one of the following and complete the related fields:
 - Select **PEAP** for username and password authentication.
 - *Configuration Name*: enter a profile name.
 - *EAP Identity*: enter the username that will be used to authenticate the camera.
 - *Password*: enter the password that will be used to authenticate the camera.
 - Select **EAP-TLS** for certificate authentication.
 - *Configuration Name*: Enter a profile name.
 - *EAP Identity*: Enter the username that will be used to authenticate the camera.

- *TLS Client Certificates*: Click **Choose File**, and then navigate to and select the PEM-encoded certificate file to authenticate the camera.
 - *Private Key*: Click **Choose File**, and then navigate to and select the PEM-encoded private key file to authenticate the camera.
 - *Private Key Password*: If the private key has a password, enter the password here.
 - *Uploaded Certificate*: The TLS client certificate and private key are uploaded to the camera. The uploaded files are used to generate a unique certificate to authenticate the camera. The unique certificate is displayed in the *Uploaded Certificate* field.
3. If appropriate, click to select the checkbox for *Authenticate Server*.
 4. Click **Save Config** to save the authentication profile.
If this is the first profile added to the camera, it is automatically enabled.
Saved configurations are listed under Saved 802.1x Configurations.

Switching 802.1X Authentication Profiles

To use a different authentication profile, select the saved configuration then click **Enable**.

Removing an 802.1X Authentication Profile

To delete one of the authentication profiles, select the saved configuration, and then click **Remove**.

Returning to the Network Page

To return to the *Network and Security* tab, *Network* page, click the **Back To Network Setup** button at the lower left of the page.

Configuring SNMP

You can use the Simple Network Management Protocol (SNMP) to help manage cameras that are connected to the network. When SNMP is enabled, camera status information can be sent to an SNMP management station.

On the *SNMP* page, you can configure the camera's SNMP settings and choose the status information that is sent to the management station page.

1. Click the **Network and Security** tab, and then click the **SNMP** button.
2. In the *SNMP Configuration* area:
 - a. Click to select the checkbox for **Enable SNMP**.
 - b. From the **Version** drop-down menu, select the preferred SNMP version. Be aware that both versions can be configured, but only one can be enabled at a time.
3. If you selected **SNMP v2c**, you can request camera status information through an SNMP Get request and receive trap notifications from the camera.
 - a. In the *SNMP v2c Settings* area, click to select the checkbox for *Enable Traps* to enable traps from the camera.
 - b. In the *Read/Write Community* field, enter the read community name for the camera. The name is used to authenticate SNMP traffic. Only SNMP management stations with the same read community name will receive a response from the camera.


- c. In the *Trap Destination IP* field, enter the IP address of the management station where the traps will be sent.
4. If you selected **SNMP v2c**, in the Available Traps area, select the traps that will be sent:
 - **Temperature Alert:** a trap notification will be sent when the camera temperature rises above or falls below the supported threshold. A notification will also be sent when the camera temperature returns to normal.
 - **Camera Tampering:** a trap notification will be sent when the camera's video analytics detects a sudden scene change.
 - **Edge Storage Status:** a trap notification will be sent when the status of the SD card changes.
5. If you selected **SNMP v3**, you can request status information through an SNMP Get request. SNMP v3 does not support traps. SNMP v3 offers greater security by allowing you to set a username and password for the camera. This camera uses SHA-1 type authentication and AES type encryption.

In the SNMP v3 Settings area, complete the following:

 - a. **Username:** enter the username that the management station must use when sending the SNMP Get request to the camera.
 - b. **Password:** enter the password the management station must use with the chosen username.
6. Click **Apply** to save the settings.

Configuring the IP Filter

On the *IP Filter* page, you can control which IP addresses are able to connect to your camera.

1. Click the **Network and Security** tab, and then click the **IP Filter** button.
2. In the IP Filter area, click to select the checkbox for Enable IP Filter, to enable IP filtering.
3. Click to select how the camera should filter IP addresses—either by allowing or denying access:
 - **Allow Access:** Select this option to only allow access to the specific IP address entries you will make below.
 -  **Caution:** If you choose to filter IP access using the Allow Access option, make sure that you configure the correct addresses to be allowed or you might be locked out of your camera.
 - **Deny Access:** Select this option to deny access to the specific IP address entries you will make below. This is the default option.
4. Add all the *IP Filter Entries* to which access will be either allowed or denied:
 - a. Click the add icon (+) to add an entry to the *IP filter Entries* list.
 - b. In the IPv4, IPv6 or CIDR range field that appears, enter the IPv4, IPv6 or CIDR range of IP addresses that you would like to filter.
 - c. Continue to add more entries to the list until you have added all of the necessary IP addresses to be filtered.

You can add up to 256 *IP Filter Entries*.
5. Click **Apply** to save the settings.



Note: If you have denied or not allowed access to the IP address you are currently using to connect to your camera, your web interface connection will close after you click **Apply**.

Managing Certificates

On the *Certificates* page, administrators can manage certificates. Certificates are used to authenticate devices and encrypt communication over the network.

In the *Certificates* area, you can view the following information:

- *Cert ID*: Used to uniquely identify the certificate.
- *Subject*: The entity a certificate belongs to: a machine, an individual, or an organization.
- *Issuer*: The entity that verified the information and signed the certificate.
- *Algorithm*: This contain a hashing algorithm and a digital signature algorithm.
- *Expiry Date*: The date when the certificate expires.
- *Type*: The type of certificate, i.e., trusted or not trusted.

Downloading Certificates

1. To download a Certificate, select it from the list.
2. Click the **Download** button.

Certificates are downloaded as .pem files.

Removing Certificates

1. To remove a Certificate, click the **Remove** button.
2. Click the **OK** button.

Downloading Certificate Signing Requests

1. To download the Certificate Signing Request (CSR), click the download **CSR button** and enter the following information:
 - *Common Name*: The primary hostname of the server.
 - *Alternative Name*: The alternative values associated with the certificate, e.g., email address, IP addresses, URIs, DNS names.
 - *(Optional) Organization*: The name of the organization requesting the certificates.
2. Click the **Download** button to download the CSR.

Uploading Certificates

1. To upload a certificate, click **Upload Cert**.
 - a. *Certificate*: click **Choose File** to upload a certificate.
 - b. *Private key*: click **Choose File** to upload a private key.
 - c. *Private key password*: enter the private key password.
2. Click the **Upload** button to upload the Cert.

Uploading CA Certificates

1. Click the **Upload** button to upload the certificate.
2. To upload a CA certificate, click **Upload CA Cert.**
 - a. *CA Certificate*: click **Choose File** to upload a CA certificate.
 - b. *CA Certificate ID*: enter the CA certificate ID.
3. Click the **Upload** button to upload the CA certificate.

Configuring Imaging



Note: If a camera with video analytics is physically moved or adjusted, or if the focus or zoom level is changed, reset the learning progress to provide accurate results. If the camera's image rate and compression or display settings are updated, the learning progress might reset automatically.

On the *Imaging and Display* page, you can control the camera's day/night and exposure settings and view the camera's live video stream.

On the *Imaging and Display* page, you can control the camera's image settings and adjust sharpness and contrast in the camera's live video stream.

Configuring General Imaging Settings

You can set the camera's zoom and focus through this page.

1. Click the **Imaging** tab, and then click the **General** button.
2. Use the **Zoom** slider to adjust the camera's zoom position.
 - To zoom out, move the slider towards the left.
 - To zoom in, move the slider towards the right.
3. To manually focus the camera, use the **Focus** buttons.
 - To focus towards zero:
 - Click << to take a large step.
 - Click < to take a small step.
 - Click **0** to focus at zero.
 - To focus towards infinity:
 - Click >> to take a large step.
 - Click > to take a small step.
 - Click **Inf** to focus at infinity.
 - Click **Auto Focus** to let the camera focus itself.



Note: After the focus is manually set, it will not change.

4. View the following information:
 - *Current Exposure*
 - *Current Gain*
 - *Current Iris*
5. Use the *Image Rotation* drop-down menu to rotate the camera image as desired. The default option is None. The image can be rotated by 90 degrees, 180 degrees or 270 degrees. The camera will reboot when applying this setting and some encoding settings will revert to their default settings.

- None
- 90 degrees
- 180 degrees
- 270 degree



Note: Image rotation should not be combined between the camera and VMS image rotation settings. Perform the image rotation either in the camera or in the VMS, but not both.

6. To set how the camera compensates for the environmental lighting conditions, define the following *Day/Night Settings*:
 - a. Use the *Day/Night Mode* drop-down menu to set how the video image switches between day and night mode.
 - **Automatic:** When the light level is above the day/night threshold, the video image will be in color. When the light level goes below the day/night threshold, the camera will automatically open the IR cut filter and switch to monochrome mode.
 - **Color:** The video image will always be in color.
 - **Monochrome:** The video image will always be monochrome.
 - **External:** The camera will open the IR cut filter and switch to monochrome mode based on the digital input circuit state.



Note: The default digital input circuit state is configured on the *Digital Inputs and Outputs* page. For more information, see [Configuring Digital Inputs and Outputs](#).
Authors: This option is not available on the Spectra Enhanced 8. It must just be for IR PTZ cameras?

- b. If you selected the **Automatic Day/Night Mode**:
 - Use the *Day/Night Threshold (gain dB)* slider to set the day/night threshold. Move the slider to select the light level when the camera switches between day mode and night mode. The slider is only available when the Day/Night Mode setting is set to **Automatic**.
 - In addition to the Day/Night Threshold (gain dB) slider, there is also have a **Night/Day Threshold** (gain dB) slider and it doesn't have a Hysteresis setting. Use The **Day/Night Threshold** (gain dB) slider to determine the light level at which the camera will switch from day mode to night mode. The **Night/Day Threshold** (gain dB) slider determines the light level at which the camera will switch from night mode to day mode. The separation between these 2 slider settings is used to avoid the hysteresis problems.
 - **Enable IR LED:** You can manually enable or disable the IR illuminators that are installed on the camera.
 - **Enable White Light LED:** For cameras with the white light LED illuminator accessory installed, use this checkbox to manually enable or disable the white light illuminator.
 - **Toggle IR Filter with Illuminator:** For cameras with the white light LED illuminator accessory installed, use this checkbox to set the behavior of the IR cut filter when the white light LED is on. When this option is enabled, the default option, the IR cut filter will behave as normal and be in color mode in a light environment and night mode in a dark environment. When this option is disabled, the camera will remain in day mode at night and rely on the white light to illuminate the scene.



- **Enable Adaptive IR Compensation:** You can enable automatic infrared adjustments through Adaptive IR Compensation. This allows the camera to automatically adjust the video image for saturation caused by IR illumination.
- **Show Auto Contrast ROI:** Enabling this option allows you view and select the region of interest. The contrast is automatically adjusted based on the selected region.
- **Enable Night Visibility Check:** You can manually enable or disable the night visibility check on a camera. The night visibility check, when enabled, performs a periodic test switching between day/night mode to check if there is sufficient light level to switch from night mode to day mode. When disabled, the camera will use a less optimal method to determine if the light level is sufficient to switch to day mode.



Note: Disabling the night visibility check could delay the camera from transitioning between night and day modes and make the transition time less optimal. For example, the camera stays in night mode 30 minutes longer than it needs to.

- Use the Narrow Illuminator drop-down menu to configure how the narrow beam of the camera's white light LED illuminator will function:
 - **Always On:** Sets the white light LED illuminator to always use the narrow beam. This setting is recommended for cameras that are mostly used for viewing distant scenes.
 - **Always Off:** Sets the white light LED illuminator to disable the narrow beam and to always use the wide beam. This setting is recommended for cameras that are mostly used for viewing nearby scenes.
 - **At Zoom Level:** Sets the white light LED illuminator to switch between the wide and narrow (tele) beams at a specific zoom setting. Use this setting to have the camera switch to the white light LED's narrow beam when the camera zooms in to the scene by the zoom level that is specified in the Zoom Step (0-100) field.
 - **Dual Light Mode:** Use the drop-down menu to choose Both or Alternate illuminator options at the zoom level. If you select Both, above a certain level of zoom, both groups of LEDs (wide and narrow) will be on. Under that zoom level, only the wide lenses will be on. On the other hand, if you select Alternate, under the zoom level, the wide LEDs will be off and the narrow LEDs will be on. Above the threshold, LEDs with narrow lenses will be on and those with wide lenses will be off.
 - **At Presets Level:** Sets the white light LED illuminator to switch between the wide and narrow beams at a specific preset setting. Use this setting to have the camera switch to the white light LED's narrow beam when the camera zooms in to the scene by the preset that is specified.
 - **Dual Light Mode:** Use the drop-down menu to choose Both or Alternate illuminator options at the presets level. If you select Both at the preset level, both groups of LEDs (wide and narrow) will be on. Under that preset, only the wide lenses will be on. On the other hand, if you select Alternate at the preset level, the wide LEDs will be off and the narrow LEDs will be on.

Tip: You can zoom the camera to the zoom level that you want the narrow white light LED beam to turn on and then click Current to input that zoom level into the field.

7. To adjust the exposure of the image, adjust the *Exposure Settings*:
 - **Flicker Control:** If your video image flickers because of fluorescent lights around the camera, you can reduce the effects of the light by setting the Flicker Control to the same frequency as your lights. Generally, Europe is **50Hz** and North America is **60Hz**.
 **Note:** Resetting this control will stop the video stream for a few seconds.
 - **Exposure:** Click to select the appropriate exposure rate from the drop-down menu. Allow the camera to control the exposure by selecting **Automatic**. In some cases, **Automatic** is the only option available.
 **Note:** Increasing the manual exposure time might affect the image rate.
 - **Maximum Exposure:** If you selected **Automatic** as the *Exposure Offset*, you can limit the automatic exposure setting by selecting a maximum exposure level. The Maximum Exposure drop-down menu is only available when the Exposure setting is set to Automatic. By setting a maximum exposure level for low-light situations, you can control the camera's exposure time to let in the maximum amount of light without creating blurry images.
 - **Priority:** If you selected **Automatic** as the *Exposure Offset*, you can set **Image Rate** or **Exposure** as the priority.
 - When set to **Image Rate**, the camera will maintain the set image rate as the priority and will not adjust the exposure beyond what can be recorded for the set image rate.
 - When set to **Exposure**, the camera will maintain the exposure setting as the priority, and will override the set image rate to achieve the best image possible.
 - **Enable Wide Dynamic Range:** You can enable automatic color adjustments through Wide Dynamic Range (WDR). This allows the camera to adjust the video image to accommodate scenes where bright light and dark shadow are clearly visible. See the section titled [Understanding Backlight Compensation \(BLC\) and Wide Dynamic Range \(WDR\)](#).
 - **Backlight Compensation:** If your scene has areas of intense light that cause the overall image to be too dark, click to select the checkbox for *Backlight Compensation*, and then enter a value (either by typing a number, or selecting one using the up and down arrows) that results in a well-exposed image. See the section titled [Understanding Backlight Compensation \(BLC\) and Wide Dynamic Range \(WDR\)](#).
 - **Maximum Gain:** To limit the automatic gain setting, click to select the the appropriate *Maximum Gain* from the drop-down menu. By setting the maximum gain level for low-light situations, you can maximize the detail of an image without creating excessive noise in the images.
 - **Iris:** You can allow the camera to control the iris by selecting **Automatic**, or you can manually set it to **Open** or **Closed**.
8. Use the Image mirror settings to control the image display (flip it or not). From the drop-down menu, click to select **None** to keep the image in the current position; click to select **Flipped** to flip the image 180 degrees.
9. If you are configuring a PTZ dome camera, you can define additional settings in the Advanced Filters area.
 - **Enable Digital Defog:** If your camera is installed in a foggy environment, select this checkbox to increase the video contrast to help make objects more visible in the scene. From

the **Defog Level** drop-down menu, select one of the available options: **High**, **Medium**, or **Low**.

- **Enable Image Stabilization:** If your camera is mounted to a pole or other surface that might be prone to shaking or vibrations, select this checkbox to enable the camera's built-in image stabilization feature.



Note: Enabling Image Stabilization will reduce the zoom capability from 36x to 30x zoom.

10. If the PTZ camera is installed upside down, you can get an upright image by configuring the "Image mirror settings":
 - **None:** no processing gets applied to the image.
 - **Flipped:** the image gets flipped by 180°.
11. Click **Apply** to save the settings.

Understanding Backlight Compensation (BLC) and Wide Dynamic Range (WDR)

- **BLC** is a feature that optimizes exposure in the foreground and background of security video. BLC uses a single exposure time for the whole image, and uses auto exposure to ignore very bright regions (or very dark, if set negative). You must choose whether the camera optimizes the foreground or the background.
- **WDR** enables advanced image processing, and helps draw out detail from both very bright and dark areas in a scene. For example: Use WDR in lobbies or store fronts with natural light streaming in through windows, where you also have dark areas in the same scene. WDR takes multiple exposures of the scene in a single time slice. Two scans are taken of each video frame, one with a short exposure optimized for brighter portions of the scene, the other longer to draw out detail in dark areas. The image processing combines the two images to form one view, incorporating the best detail and clarity across the entire scene.

If you enable both BLC and WDR, the camera will deliver the detail you will see in WDR-only mode, but will ignore optimization on the very brightest (or darkest) portions of the image.

Adjusting White Balance Settings

1. Click the **Imaging** tab, and then click the **White Balance** button.
2. Use the **Zoom** slider to adjust the camera's zoom position.
 - To zoom out, move the slider towards the left.
 - To zoom in, move the slider towards the right.
3. To manually focus the camera, use the **Focus** buttons.
 - To focus towards zero:
 - Click **<<** to take a large step.
 - Click **<** to take a small step.
 - Click **0** to focus at zero.

Esprit Compact Operations Manual

- To focus towards infinity:
 - Click >> to take a large step.
 - Click > to take a small step.
 - Click **Inf** to focus at infinity.
- Click **Auto Focus** to let the camera focus itself.



Note: After the focus is manually set, it will not change.

4. View the following information:

- *Current Exposure*
- *Current Gain*
- *Current Iris*

5. Adjust the video image as required.

You can either use a preset configuration, or you can create your own custom configuration. Use the **Preset** drop-down menu to select the preferred configuration:

- Pelco:** This preset provides the recommended balance of brightness and color for video surveillance.
- Standard:** This preset is configured for general day/night changes in an indoor or outdoor scene.
- Vivid:** This preset provides increased color and brightness for a more saturated image.
- Custom:** Select this option to manually adjust the following image settings:



Note: The *Contrast* setting is disabled if you selected *Enable Wide Dynamic Range*. See the section titled [Configuring General Imaging Settings](#)

- **Saturation:** You can adjust the video's color saturation by entering a percentage number.
0 creates a black and white image, while 100 creates intense color images.
 - **Sharpness:** You can adjust the video's sharpness by entering a percentage number.
0 applies the least amount of sharpening, while 100 applies the most sharpening to make the edges of objects more visible.
 - **Brightness:** You can adjust the video's brightness by entering a percentage number.
0 applies the least amount of contrast, while 100 applies the most contrast between objects in the image.
 - **Contrast:** You can adjust the video's contrast by entering a percentage number.
0 applies the least amount of contrast, while 100 applies the most contrast between objects in the image.
- Move the *Noise Filter Strength* slider slightly to the left or right to adjust the amount of noise vs. blur in the scene. This reduces image noise by averaging the noise over several frames.



Note: Start by making small adjustments only because applying excessive changes might degrade the overall image quality.

If the image looks noisy, move the slider to the right to reduce the amount of noise in the scene and decrease the bandwidth used.

Esprit Compact Operations Manual

If the image looks blurry, move the slider to the left to reduce the amount of blur in the scene and increase the bandwidth used.

By default, the slider is set to the middle, which is 50; on PTZ cameras, the default value is set to 60.

6. Use the **White Balance** drop-down menu to select how the white balance settings are controlled:
 - **Automatic**: The camera will automatically control the white balance.
 - **Custom**: Manually set the **Red** and **Blue** levels.
7. Click **Apply** to save the settings.

Using Window Blanking

On the *Window Blanking* page, you can set window blanks (privacy zones) in the camera's field of view to block out areas that you do not want to see or record. The camera supports up to 64 window blanks.

Setting a Window Blank

1. Click the **Imaging** tab, and then click the **Window Blanking** button.
2. To add a window blank (privacy zone), click **Add**. A window blank box is added to the video image.



Note: For Pelco PTZ cameras, the window blank might shift slightly when the camera performs an e-flip. If this is a concern, we recommend drawing a slightly larger box or disabling e-flip for that camera. For more information on disabling e-flip, see [Defining PTZ Limit Stops](#).

3. To define the window blanking box, perform any of the following:
 - a. Drag any side of the box to resize the window blank. Window blank boxes can only be rectangular in shape.
 - b. Click inside the box then drag to move the window blank box.
4. Click **Apply** to save the settings.

Deleting a Window Blank

1. Use one of the following methods to delete a window blank (privacy zone):
 - In the list of window blanks, click to select the name of the window blank to delete (**Privacy Zone [#]**), and then click **Remove**.
 - Click to select the window blank box to delete, click the **X** at the top-right corner of the gray box to delete the window blank box, and then click **OK** in the confirmation dialog box.
2. Click **Apply** to save the settings.
3. Click **OK** in the confirmation dialog box.

Configuring PTZ Settings

Pelco PTZ cameras use many of the same settings as other High Definition IP cameras. The following settings are only available on the Esprit CompactEnhanced 2 Series WDR PTZ Camera.

Creating PTZ Tours

For PTZ cameras, you have the option of running Tours from the Live View page. Tours allow the PTZ camera to automatically move between a series of preset positions, and can be set to pause at each preset for a specific amount of time for video monitoring.



Note: Add all relevant presets before you create a new tour. For more information, see [Using Camera Presets](#).

To create a tour, complete the following:

1. Click **PTZ** tab, and then click the **Preset Tours** button.
2. Click **Create New Tour**.
The *New Tour* dialog is displayed.
3. In the *Name* field, type in a name.
4. In the *Mode* drop-down menu, select one of the following:
 - **Sequential:** The PTZ camera will go to each preset in the set order.
 - **Random:** The PTZ camera will go to each preset in random order.
5. (Optional) Click to select the *Set as Default Tour* checkbox if you want this tour to run automatically, and then enter the amount of time in minutes that the PTZ camera must be idle for before this tour automatically begins.
6. In the *Tour Pause Duration (Minutes)* field, enter the amount of time before the tour repeats. Tours repeat until manually stopped, or until other PTZ controls are used.
7. To add a preset, click Add Preset and a preset is added to the list.
 - a. In the Preset column, select a preset from the drop-down menu.
 - b. In the *Move Speed* column, enter a percentage of the maximum speed defined on the *Positioning* page. (Click **Positioning** at the top of the *PTZ* page to set the speed.) This option sets how fast you want the PTZ camera to move to this preset. The *Move Speed* is 80% by default.
 - c. In the *View Time* column, enter the amount of time you want the PTZ camera to stay at this preset position. The view time is 10 seconds by default.
 - d. Continue until all the presets for this tour have been added.
8. To remove a preset, click the *Remove Preset* icon (✕) to the far right of the preset.
9. To re-order a preset, click the *Move Preset Up* and *Move Preset Down* arrows (↑ ↓) or click and drag the left edge of the preset through the list and drop it to the correct location.
10. Click **Apply** to save the settings.

Editing PTZ Tours

1. From the left menu pane, select **PTZ Tours**.
2. Click **Edit** (Edit) to the right of the tour that you want to edit.

3. Make the appropriate changes.
4. To undo the changes that you've made, click **Discard Changes**.
5. Click **Apply** to save the settings.
6. To delete the tour, click **Delete**, and then click **OK** in the confirmation dialog box.

Defining PTZ Limit Stops

Depending on where the PTZ camera is installed, you might want to limit the movement and zoom of the camera so that obstructions are never in view. For example, if the PTZ camera is installed close to the side of a building, you can set the limits so that the PTZ camera cannot move to show the wall against which it is installed.



Note: Features and options are disabled if they are not supported by the camera.

1. Click the **PTZ** tab, and then click the **Positioning** button.
2. Use the **Zoom** slider to adjust the camera's zoom position.
 - To zoom out, move the slider towards the left.
 - To zoom in, move the slider towards the right.
3. To set the **Pan/Tilt Speed Limit**, enter a maximum number of degrees per second to limit the speed that the camera moves when you manually control its mechanical pan and tilt. Enter a number between the available range displayed on the right.
4. Set the maximum Pan/Tilt Speed Limit in the same way.
5. Click **Apply** to save your settings.

Configuring the Camera Washer

1. Click the **PTZ** tab, and then click the **Washer** button.
2. If necessary, click to select the checkbox for *Enable Washer*. This is the default state.
3. From the *Washer Location* drop-down menu, click to select the appropriate preset.



Note: Add all relevant presets before you configure the camera washer. For more information, see [Using Camera Presets](#).

4. Enter a value in the *Wiper On Delay* field, either by typing-in a number or using the up and down arrows in the field.

This is the time it will take for the wiper to start wiping after it has moved into position to be sprayed by the washer. The longer the delay, the more time the fluid from the washer has to soak on the glass and breakdown any grime. Likewise, you can start wiping immediately and during the wash time, so that the wiper and washer fluid are working together to remove grime.
5. Enter a value in the *Washer period* field, either by typing-in a number or using the up and down arrows in the field.

This is the amount of time that the camera will stay pointed at the washer nozzle where the washer will spray the window with fluid. There are two reasons for this; 1) the tube length might vary, and increase or decrease the time it takes for the fluid to reach the window, and 2) more fluid might be necessary to assist in cleaning the window (for example: dust should not need much fluid, where as dried dirt or oil and grease might need more spray time).
6. Enter a value in the *Wiper Off Delay* field, either by typing-in a number or using the up and down arrows in the field.

This is the amount of time that the wiper will stay active until it shuts off. It allows you to control of the number of wipes before turning off. The rate is one wipe every four seconds. If you wanted five wipes, you would set the duration to 20 seconds.

7. Click **Apply** to save the settings.

Setting up PTZ Compass

Based on the orientation of the camera, cardinal direction may be displayed along with other information on the Overlay. Directional information might be useful in an exterior environment.

1. Click the **PTZ** tab, and then click the **Compass** button.
2. Select the **Enable Compass Overlay** checkbox. If it is the first use, on the overlay, new text will appear: "Compass uninitialized."
3. Point the camera to one of the cardinal directions (e.g. North).
4. Click one of the buttons with the corresponding direction (e.g. **Set North**). The camera will connect its current position with a new setting. Now the new text that appears should change to a notation of the world direction (e.g. 0.00° N"). This value should change as the camera moves left or right.
5. To remove the cardinal direction setting, click **Uninitialize Compass**. The text should say, "Compass uninitialized".
6. To remove the display of the world direction, clear the **Enable Compass Overlay** checkbox. You do not need to uninitialize it first. If you don't, the camera will still track its direction without displaying it on the overlay.

Configuring A/V Streams

Configure compression and image rate, smart compression, RTSP stream URI, Still Image URI, and advanced smart compression on the A/V Streams page.

Compression and Image Rate

On the *Compression and Image Rate* area, you can change the camera's compression and image quality settings for sending video over the network. You can change the camera's compression and image quality settings separately for primary, secondary, and tertiary streams.



Note: If a camera with video analytics is physically moved or adjusted, or if the focus or zoom level is changed, reset the learning progress to provide accurate results. If the camera's image rate and compression or display settings are updated, the learning progress might reset automatically.


To enable easy access and lower bandwidth usage, the web interface only displays video in JPEG format. The settings on this page only affect the video transmitted to the network video management software.



Note: The camera might automatically adjust compression quality in order to abide by the bandwidth cap specified.

Follow these steps for each of the primary, secondary, and tertiary streams to change the compression and image quality settings for each stream.

1. Click the **A/V Streams** tab, and then click the **Video Configurations** button.
2. In the *Compression and Image Rate* area:
 - a. In the **Format** drop-down menu, select the preferred streaming format for displaying the camera video in the network video management software.

If you are using the Onboard Storage feature, then **H.264** or **H.265** must be used. For more information, see [Enabling Onboard Storage](#).
 - b. In the **Max Image Rate** field, enter how many images per second you want the camera to stream over the network.
 **Note:** Adjusting the image rate across the maximum fps boundary will stop the video stream for a few seconds.

If the camera is operating in High Framerate mode, then the maximum image rate is increased. For more information on the High Framerate mode, see [Configuring General Settings](#).
 - c. In the **Max Quality** drop-down menu, select the desired image quality level.

Image quality setting of 1 will produce the highest quality video and require the most bandwidth.
 - d. In the **Max Bitrate** field, enter the maximum bandwidth the camera can use.
 - e. In the **Resolution** drop-down menu, select the preferred image resolution.
 - f. In the **Min Keyframe Interval** field, enter the number of frames between each keyframe.
3. Click **Apply** to save the settings.

Enabling and Configuring Smart Compression

Smart Compression technology operates by separating foreground objects and background areas, then reduces bandwidth by increasing compression to the background areas. In this way, maximum quality is retained for subjects of interest while reducing bandwidth for unchanging backgrounds.

When enabled, the camera will automatically switch to idle scene mode settings when there are no motion events detected. A motion event is when the camera detects pixel motion in the scene. For more information, see the section titled [Configuring Motion Detection](#).

The camera uses pixel change motion to detect foreground objects and therefore uses the standard Motion Detection sensitivity settings of the camera.

1. Click the **A/V Streams** tab, and then click the **Video Configurations** button.
2. In the *Smart Compression Settings* area, click to select the checkbox for *Enable* to enable *Smart Compression*.
3. In the **Min Image Rate** field, enter how many images per second you want the camera to stream when there is no motion in the scene.
4. In the **Idle Keyframe interval** field, enter the number of frames between each keyframe (between 1 and 254) when there is no motion in the scene.
5. In the *Bandwidth Reduction* drop-down menu, click to select one of the options:
 - **Low**
 - **Medium** (recommended)
 - **High**
 - **Custom**
6. Click **Apply** to save the settings.
7. If you chose **Custom** for the *Bandwidth Reduction*, see the section titled [Configuring Smart Compression Advanced Settings](#).

Viewing the RTSP Stream URI

You can only view the RTSP stream address in the camera web interface. The RTSP Stream URI allows you to watch the camera's live video stream from any application that supports viewing RTSP streams, including many video players.



Note: You can only generate the RTSP stream address in the camera web interface.

1. Click the **A/V Streams** tab, and then click the **Video Configurations** button.
2. View the auto-generated URIs in the RTSP Stream URI area:
 - **Unicast** — Use this URI to view the video stream from one video player at a time.
 - **Multicast** — Use this URI to view the video from more than one video player simultaneously.
3. To view the RTSP stream:
 - a. Copy and paste the appropriate URI into your video player. **DO NOT** open the live video stream yet.
 - b. Add your username and password to the beginning of the address in this format:
rtsp://<username>:<password>@<generated RTSP Stream URI>/

For example: `rtsp://admin:admin@192.168.1.79/defaultPrimary?streamType=u`

- c. Open the live video stream.

Accessing the Still Image URI

On the *A/V Streams* tab, *Video Configurations* page, you can access the last still image frame that the camera recorded.

1. Click the **A/V Streams** tab, and then click the **Video Configurations** button.
2. In the *Still Image URI* area, click the link.
 - The last recorded frame of video from the camera's tertiary stream is displayed if the encoding type is set to H.264 or H.265. The last frame comes from the primary stream, maximum resolution, if the encoding is set to MJPEG.
 - You can save or print the image directly from the browser.


Saving or Restoring Video Configurations

After you have updated all settings on the Video Configurations page, do one of the following:

- Click **Apply** to save the settings.
- Click **Restore Defaults** to restore all settings (saved and unsaved) to the default settings.

Configuring Smart Compression Advanced Settings

If you enabled *Smart Compression* on the *Video Configuration* page (see the section titled *Enabling and Configuring Smart Compression*), configure the Smart Compression Advanced Settings.

1. Click the **A/V Streams** tab, and then click the **Smart Compression** button.
2. Click **Head 1**.
 **Note:** These settings are head specific. You can set each head with its own Smart Compression configuration. Follow these steps for **Head 1** and repeat for the other heads.
3. In the **On Motion** section, **Background Quality** field, enter the compression quality for the background (between the default of 6 and the lowest setting of 20).
4. In the **On Idle Scenes** section:
 - **Post-motion delay** field, enter the delay (in seconds) after motion has ended before the camera drops into idle scene settings (between 5 and 60)
 - **Image Rate** field, enter the encoding frame rate (images per second) when there is no motion in the scene.
 - **Quality** field, enter the compression quality when there is no motion in the scene (between 6 and 20).
 - **Max Bitrate** field, enter the maximum number of kilobytes per second when there is no motion in the scene.
 - **Keyframe Interval** field, enter the number of frames between each keyframe when there is no motion in the scene (between 1 and 254 frames).
5. Click **Apply** to save the settings.

Configuring Events

Use the *Events* tab to configure *Motion*, *Sabotage*, and *DIO* settings.



Note: Other analytics events that are not available in the camera UI can be configured using CCT.

Configuring Motion Detection

On the *Motion Detection* page, you can define the green motion detection areas in the camera's field of view. Motion detection is ignored in areas not highlighted in green.

To help you define motion sensitivity and threshold, motion is highlighted in red in the image panel.



Note: This motion detection setting configures pixel change detection in the camera's field of view. If you are configuring a Pelco video analytics camera, you will need to configure the detailed analytics motion detection and other video analytics features through the Client software.

1. Click the **Events** tab, and then click the **Motion** button.
2. Define the motion detection area.
The entire field of view is highlighted for motion detection by default. To define the motion detection area, use any of the following tools:
 - Click **Clear All** to remove all motion detection areas on the video image.
 - Click **Set All** to set the motion detection area to span the entire video image.
 - To set a specific motion detection area, click **Select Area** then click and drag anywhere on the video image.
 - To clear a specific motion detection area, click **Clear Area** then click and drag over any motion detection area.
 - Use the **Zoom In** and **Zoom Out** buttons to locate specific areas in the video image.
3. In the **Sensitivity** field, enter a percentage number to define how much each pixel must change before it is considered in motion.
The higher the sensitivity, the smaller the amount of pixel change is required before motion is detected.
4. In the **Threshold** field, enter a percentage number to define how many pixels must change before the image is considered to have motion.
The higher the threshold, the higher the number of pixels must change before the image is considered to have motion.
5. If the camera is connected to a third-party video management system (VMS), and then click to select the checkbox for *Enable Onvif MotionAlarm Event*.
When it is enabled, the camera can send motion alarm information to the VMS according to the appropriate ONVIF protocol.
6. Click **Apply** to save the settings.

Analytics Configuration

On the *Analytics* page, you can enable, suspend, or reset Self Learning Analytics.

1. Click the **Events** tab, and then click the **Analytics Configuration** button.
2. Click to select the checkbox for **Enable Self Learning** to enable self learning analytics.

3. Click to select the checkbox for **Suspend Self Learning** to temporarily suspend self learning analytics.
4. Click **Apply** to save the settings.
5. Click Restore Defaults to restore the default settings.

Configuring Digital Inputs and Outputs

On the *Digital Inputs and Outputs* page, you can set up the external input and output devices that are connected to the camera. This option does not appear for cameras that do not support digital inputs and outputs.

1. Click the **Events** tab, and then click the **DIO** button.
2. To configure a digital input:
 - a. Enter a name for the digital input in the **Name** field.
 - b. Select the appropriate state from the **Circuit State** drop-down menu. The options are:
 - **Normally Open**
 - **Normally Closed**
 - c. Click **Apply** to save the settings.
After the digital input is connected to the camera, you will see the connection status in the **Circuit Current State** field. The status is typically *Open* or *Closed*.
3. To configure a digital output:
 - a. Enter a name for *Digital Output 1* or *Digital Output 2* (if present) in the Name field.
 - b. Select the appropriate state from the *Circuit State* drop-down menu.
 - c. the *Duration* field, enter how long the digital output is active when triggered. You can enter any number between 100 and 86,400,000 milliseconds.
 - d. Click **Trigger** to manually trigger the digital output from the web interface.
 - e. Click **Apply** to save the settings.

Esprit Compact Operations Manual



Manufacturer: Videotec s.r.l.
Address: Via Friuli, 6-I-36015 Schio (VI) - Italy
(+39) 0445 697411 Tel

Pelco, Inc.
625 W. Alluvial Ave., Fresno, California 93711 United States
(800) 289-9100 Tel
(800) 289-9150 Fax
+1 (559) 292-1981 International Tel
+1 (559) 348-1120 International Fax
www.pelco.com

Pelco, the Pelco logo, and other trademarks associated with Pelco products referred to in this publication are trademarks of Pelco, Inc. or its affiliates. ONVIF and the ONVIF logo are trademarks of ONVIF Inc. All other product names and services are the property of their respective companies. Product specifications and availability are subject to change without notice.

© Copyright 2022, Pelco, Inc. All rights reserved.